Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



• Not for commercial use. For residential use only.



• Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



• Children should not climb or jump on the furniture.



• Do not write on furniture without a padded barrier to protect the surface.



 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine.
Whenever possible cover the product and /or place under patio or awnings.



• Stains may be removed with mild soap solution and damp cloth.




• Keep away from sources of ignition.



• Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Please look in the Backrest Panel for hardware packs.


CHAIR



Part List:			
Label	Picture	Description	Qty
А		Left Arm Panel	1
В		Right Arm Panel	1
С		Front Support Bar	1
D		Seat Panel	1
E		Backrest Panel	1
<u>Hardware</u>			
No.	Picture	Description	Qty
1)		Screw (M7 x 70mm)	7
2		Bolt (M6 x 55mm)	3
3		Washer (M8 x 20 x 2mm)	3
4		Sleeve Nut (M6 x 15 mm)	3
(5)		Allen Wrench	2

Assembly Preparation

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-


Assembly Steps



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.




Unpack and place all parts on a clean, non-marring surface.



With the help of your adult partner, place the Backrest Panel (E) stand up as shown in picture onto a clean, soft surface to avoid any scratches or damages to the product.

Align the tenon of Seat Panel (D) into the mortise of the Backrest Panel (E) and then, affix Seat Panel (D) with Backrest (E) by using Screws (1) and Allen Wrench (5).

Do not fully tighten the Screws.




With the help of your adult partner, attach the Right Arm Panel (B) to the assembled part in Step 2 as shown above. Then:

Step 3.1, Affix Right Arm Panel (B) with Backrest Panel (E) by using Bolt (2), Washer (3), Sleeve Nut (4) and Allen Wrench (5).


Step 3.2, Affix Right Arm Panel (B) with Set Panel (D) and Front Support Bar (C) by using Screws (1) and Allen Wrench (5).

Do not fully tighten the Screws and Bolts.



With the help of your adult partner, turn the assembled part in Step 3 to the opposite side and then repeat the same process at Step 3 to affix Left Arm Panel (A) to Backrest Panel (E), Seat Panel (D) and Front Support Bar (C) as shown above.

Do not fully tighten the Screws and Bolts.



Inspect it and make sure all parts are adequately connected.

Turn the Chair right side up.

Gently and gracefully, sit onto the Chair.

This will help to align all the parts at all joint areas.

Then get off the Chair and in a sequential manner, gradually tighten all Screws and Bolts at all joints until evenly connected.

If there are still wobbles, loosen the Screws, Bolts and execute this same process.

Adjust Pre-installed Leveler height for balance as shown above.

WARNING!! IF CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Your Chair is ready for use.

This Chair can only be used on a flat, level surface.