




MANHATTAN
COMFORT

Assembly Guide

Model: 9GMC1 / 9GMC2 / 9GMC3 / 9GMC4



Tall Cabinet





Stuck? Questions? We are here to help.

1-888-230-2225

help@manhattancomfort.com



In order to ease the assembly,
you should separate and identify the parts first



Do not place the parts directly onto the floor.
Use a cardboard sheet or a mat to place the
parts, during the separation and assembly.

IMPORTANT


**In order to avoid severe or even fatal injuries, follow the
instructions carefully.**

**Tools Needed (not supplied)*




IDENTIFICATION OF PARTS

		IDENTIFY THE COLOR OF YOUR CABINET							DIMENSION		
Nº	DESCRIPTION	BLACK MATT	WHITE MATT	BLUE	GRAY	MATERIAL	QUANTITY		LENGTH	WIDTH	THICKNESS
P1	LEFT SIDE SMART	3000009160	3000009313	3000009263	-	STEEL	1	PC	25,31"	13,74"	0,67"
P2	RIGHT SIDE SMART	3000009161	3000009314	3000009265	-	STEEL	1	PC	25,31"	13,74"	0,67"
P3	CEILING 1DOOR SMART	3000009414	3000009412	3000009408	-	STEEL	1	PC	13,70"	13,62"	0,94"
P4	REAR 1DOOR SMART	3000009154	3000009308	3000009267	-	STEEL	1	PC	13,74"	13,43"	1,26"
P5	SHELF SMART	3000009151	3000009317	3000009268	-	STEEL	1	PC	13,74"	12,80"	0,63"
P6	BACK 1DDOR SMART	3000009164	3000009320	3000009269	-	STEEL	1	PC	24,02"	12,87"	0,67"
P7	DOOR RIGHT SMART	3000009318	3000009353	3000009270	3000009157	STEEL	1	PC	23,70"	12,24"	0,63"
P8	FRAME SMART FRONT	3000009172	3000009309	3000009272	-	STEEL	2	PC	13,74"	8,74"	0,59"



ASSEMBLED PRODUCT:
H: 29.92" W:13.77" L:13.77"



*Maximum weight
supported distributed*

Hardware list

F1


1000008297



Qty. 2

F2


1000008616



Qty. 2

F3

1000009033



Qty. 1

F4


1000000281 - WHITE
1000007352 - BLACK
1000010221 - BLUE



Qty. 2

F5


1000010136



Qty. 1

F6


1000008285



Qty. 2

F7

3000009645 - WHITE
3000009643 - BLACK
3000009649 - BLUE
3000009647 - GREY



Qty. 1


F8

1000008285






Qty. 1


1 - Attach the **FRAME** part on the **LEFT SIDE** and **RIGHT SIDE** parts in the indicated direction.





- 1 - Check the alignment of the holes on the fitted parts.
- 2 - The hole in the horizontal bar of part **FRAME**, should be up.



02



- 1 - With the end of **F3**, smash the safety claw, locking part **FRAME** to part **LEFT SIDE** and **RIGHT SIDE**.






03

1 - Identify the cutout on the top end of the **BACK** part.


2 - Attach the **BACK** part on the **LEFT SIDE**, **RIGHT SIDE** and **FRAME** parts.

3- Slide part **BACK** to support on parts **LEFT SIDE** and **RIGHT SIDE**.





04

2x





1 - With the end of **F3**, smash the safety claw, locking part **BACK** to part **LEFT SIDE** and **RIGHT SIDE**.





05

- 1 - Attach the joint of the front of the **REAR** part under the **FRAME** part.
- 2 - Lower the **REAR** part as indicated.




06

- 1 - Check all the fittings before moving forward.




07


1 - Attach the **CEILING** part on the parts **LEFT SIDE** and **RIGHT SIDE**.



2 - Pull the front of the **P3** part.




1 - With the end of **F3**, smash the fety claw, locking part **CEILING** to part **BACK**.




09

1- Slightly turn the **SHELF** part and place it inside the cabinet, as indicated.
2- Check all the fittings before continuing.



10



1 - Lay the cabinet against the wall and mark the hole.



IMPORTANT: CABINET MUST BE ATTACHED TO THE WALL


11

1 - Drill the wall on the marked point, using a 1/2" drill bit.



12


1 - Insert the metal part of the bushing into the hole until it overcomes the wall.



WALL

0


2 - Pull the bushing driving it against the wall and then push the plastic ring until it leans close to the wall




Plastic ring

WALL



0



3 - Break the bushing's rods




WALL





- 1 - Insert the screw **F2** into the hole of part **BACK**
- 2 - Turn screw **F2** with part **F3** clockwise
- 3 - Press part **F4** against the heads of the **F2** screws.

2x



2x



F2



2X

F3



1X


F4



2X


14

- 1 - Attach the **F5** into the **FRAME** part.



1x

F5




F5



1X


15

1 - Attach the **F7** handle to the door **DOOR** as indicated below



16

1 - Attach the **F6** into the **DOOR** holes.




F6



2X



17

- 1 - Attach part **DOOR** to the bottom of the cabinet through part **DOOR**
- 2 - Finish engaging part **DOOR** through the pivoting wrench as shown below.



18

- 1 - Glue **F8** to part **DOOR** in the indicated area..



19

TAKING GOOD CARE OF YOUR CABINET

Cleaning and caring instructions:

- Avoid dragging objects on top of the cabinet. They might scratch the finishing.
- Only non-abrasive natural chemical products are recommended to clean your cabinet. Simply wipe the cabinet down with a wet cloth to remove the cleaning product excess.
- Never clean the cabinet with scouring powders, steel scrubber pads or any other product which can scratch its surface.
- Chemical products are not recommended.
- Cabinet surfaces should not be covered with colored plastic or paper sheets.
- Acid substances like salt, onion, ketchup and mustard must remain properly stored in sealed containers.
- Avoid the direct contact of water with other surfaces than the sink, as the humidity can affect the durability of the cabinets.
- Avoid cabinets exposure to direct Sun light. Drapers suggested.
- For technical assistance outside Brazil, please, contact the store where you purchased your product.
- This guidance should be saved for future reference, if necessary.

BEWARE: Do not use a damp cloth to clean the cabinet. Excessive moisture can damage its surface.

ATTENTION

To avoid serious or irreparable damage to the product, follow the instructions carefully.



WARRANTS TERMS

This product has the guarantee for a period of twelve (12) months, this limited warranty is effective from the date of the original consumer purchase. Proof of original purchase date is required to obtain service or replacement under this limited warranty. Once the defect of manufacture has been verified, the consumer should contact the store where he purchased the product. In the warranty period, any defective parts will be replaced free of charge by another of the same line and model. The installation and assembly in the residence of the customer is not the responsibility of the factory or the store. The assembly must correctly follow the instructions inside the packaging of each module.

ITEMS EXCLUDED FROM WARRANTIES

This limited warranty does not cover:

1. In-home service including, but not limited to, service calls to correct the installation of any Manhattan Comfort Smart Diy products or to instruct the consumer on how to use or install them.
2. Damage resulting from improper handling or shipping of products, or products damaged by accident, alteration, misuse, abuse, fire, flood, improper installation, acts of God, neglect, corrosion, modification or mishandling.
3. All travel, transportation, shipping or freight fees to deliver replacement products or to return defective products.
4. Factory specified replacement parts or product replacement when your product is used in other than normal, single-family household use, such as a commercial environment or handled in a manner contrary to published user or operator instructions and/or installation instructions.
5. Aesthetic damages including scratches, dings, dents or cracks that do not affect the structural or functional capability of the product.
6. Any labor costs during the limited warranty period.
7. Damage resulting from improper loading beyond the specified maximum weight capacity outlined in the assembly instructions provided with the product including overloading of hooks, baskets, shelves, cabinets, and other Manhattan Comfort Smart Diy accessories used with the product.
8. Surfaces damaged due to chemical interaction resulting in corrosion of paint or metal.

The cost of repair or replacement under these excluded circumstances shall be borne by the customer.

DISCLAIMER OF IMPLIED WARRANTY


Implied warranties, including any implied warranty of merchantability or implied warrant of fitness for a particular purpose, are limited to one year or shortest period allowed by law.

LIMITATION OF REMEDIES; EXCLUSION OF INCIDENTAL AND CONSEQUENTIAL DAMAGES

Your sole and exclusive remedy under this limited warranty shall be product repair as provided herein. Manhattan Comfort Smart Diy shall not be liable for incidental or consequential damages.



MANHATTAN
COMFORT



Stuck? Questions? We are here to help.

1-888-230-2225

help@manhattancomfort.com