
Dining Chair



N715P251912

Please read all instructions carefully:

- 1. Have 2 adults on hand for assembly.
- 2. 50% Tighten before fixing all screws, Allen wrench is
- 2. 50 / 0 Fighten before fixing an serews, Thien wrenen is
- 3. Place the item on a flat ground to adjust and make sure it remains stable.
- 4. Tighten up all screws with tools gradually.
- 5. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 6. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
- 7. Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

Care & Maintenance



Not for commercial use. For residential use only



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



• To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



 Do not write on furniture without a padded barrier to protect the surface.




To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Stains may be removed with mild soap solution and damp cloth..




Dust and pick-up spills using a clean, non-colored, lint-free cloth.





Part List: В C D Left hind leg (1 pc) Seat frame (1 pc) Backrest bar 1 (1 pc) Backrest bar 2 (1 pc) \mathbf{E} H G Armrest (2 pcs) Right front legs (1 pc) Left front legs (1 pc) Right hind leg (1 pc) K M Seat cushion (1 pc) Back cushion (1 pc)


Hardware list: N715P251912 2 4 Screw M4*15 (4pcs) Screw M4*25 (4pcs) Screw M6*50 (6pcs) Allen Key (2 pcs) 5 6 7 8 **Bolt M6x50 (4 pcs)** Steel panel (2pcs) Flat Washer 7/20x1.5 (4 pcs) Screw M6*90 (8pcs) 9 **Screw driver** (Not provided)


05-10














STEP 8






STEP 9



FINISH

Dining Table



N715P251913

Please read all instructions carefully:

- 1. Have 2 adults on hand for assembly.
- 2. 50% Tighten before fixing all screws, Allen wrench is
- recommended instead of an electric drill.
- 3. Place the item on a flat ground to adjust and make sure it remains stable.
- 4. Tighten up all screws with tools gradually.
- 5. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 6. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
- 7. Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

Care & Maintenance



Not for commercial use. For residential use only



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



 Do not write on furniture without a padded barrier to protect the surface.




To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.




Stains may be removed with mild soap solution and damp cloth...





Dust and pick-up spills using a clean, non-colored, lint-free cloth.





Hardware list: N715P251913 2 1 4 Allen Key (2 pcs) Bolt M6x35 (12 pcs) **Bolt M6x55 (8 pcs) Bolt M8x70 (8 pcs)** 5 6 7 8 Blind Rivet Nut M6x35 (4 pcs) | Flat Washer 7/20x1.5 (12 pcs) **Bolt M6x25 (4 pcs)** Flat Washer 9/20x1.5 (8 pcs)





STEP 4

