


DOUBLE HAMMOCK WITH 9ft STEEL STAND

WEIGHT CAPACITY:450 LBS



CONTACT US FIRST!

If you have any questions after receiving the package or during use, please contact us.
WE CAN HELP!

Search LazyDaze Hammocks



Customer Service

 support@lazydazehammocks.com  (626) 899-5788

READ BEFORE USE

- Ensure all snap-buttons are fully engaged into the mounting holes, and all hardware is securely fastened.
- Ensure feet are evenly distributed.
- Only use on a flat, level surface.



WARNING: Do not leave children unattended while on the hammock



WARNING: Not to be used as a swing



WARNING: Always enter your hammock in the middle



WARNING: Regularly check hook and wingnuts are tight

GENERAL USE & CARE

- **SAFE USE:** Follow all safety statements and warnings. Always move slowly when getting in and out of any hammock. This stand could cause serious injury including, but not limited to, the stand tipping over or collapsing if user(s) stand up in, swing, bounce, jump, or perform any other excessive movement while using a hammock.
- **STORAGE:** Limit exposure to precipitation and high moisture as it may cause the non-coated surfaces to rust. Cover or store indoors when the hammock is not in use. Store in a cool, dry location.
- **INSPECTION:** Ensure the stand is assembled correctly and the hardware is securely tightened before every use. Do not use the stand if parts are missing, broken, damaged, or worn. Additionally, always inspect your hammock.
- **CLEANING:** Wipe surfaces with a soft cloth and warm water. Dry the stand after cleaning to prevent rust.
- **SCRATCHES:** The powder coating on the stand is tough and durable, but even under normal use, some scratching is inevitable. To avoid excessive rust, wipe scratched areas as needed to remove moisture.

WARRANTY


- LazyDaze is warranted for a period of twelve (12) months limited from the date of purchase. During the warranty period, if the product becomes defective due to faulty materials or workmanship during normal use, we will replace the parts or the entire product free of charge.
- **THIS WARRANTY DOES NOT APPLY TO GOODS WHICH ARE MISUSED, OR ABUSED, OR DAMAGED FROM SETUP OR ASSEMBLY, OR NOT USED IN ACCORDANCE WITH SELLER'S INSTRUCTIONS. NORMAL WEAR OF GOODS IS NOT INCLUDED IN THIS WARRANTY.**

ASSEMBLY

Please confirm that you have received all the parts according to the list below before assembling.
Please contact <support@lazydazehammocks.com> for missing or damaged parts.


Carefully read all assembly steps, care instructions,
and safety information before using this product.

PART LIST

No.	Description	QTY	Image
1	Base	2	
2	Crossbar	1	
3	Hammock Frame Bar	2	
4	Hook, Washer & Wingnut	2	
5	Bolt	5	
6	Camping Carry Bag	1	

ASSEMBLY STEPS

1. Place all the pieces on the floor
2. Connect the crossbar with the bases, screw the bolts tightly into place
3. Connect the hammock frame bar with the bases, screw the bolts tightly into place
4. Put the hook and washer in the appropriate hole to suit hammock size
5. Screw the wingnut to fix the hook
6. Hang the hammock according to the photograph (below)- hammock should only have a slight curve when first fitted to accommodate weight. Adjust as cotton stretches





Hammocks



Hammock Combos



Hammock Chairs



Stands

To be Continued...

Thanks For Choosing US!

Lazy Daze Hammocks
Weaving Dreams, Connecting Lives



10 Years

R&D Experience



300+

Customers Worldwide



180+

Registered Patents



30+

Exporting Countries

Any Problem We Can Help!

Search LazyDaze Hammocks



Customer Service



support@lazydazehammocks.com



(626) 899-5788