


ASSEMBLY INSTRUCTIONS

TWIN BED

If you have any questions, please feel free to contact us.

Email: lowes.team@qualfurn.net



WF313047

ASSEMBLY INSTRUCTIONS



SAFETY WARNINGS




1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk:

Upper bunk (bunk bed and tribed included)

Bed Type	Length	Width	Thickness
Twin Standard	74" - 75"	37 $\frac{1}{2}$ " - 38 $\frac{1}{2}$ "	6" max

2. Replacement parts, including additional guardrails, maybe obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC. 18961 ARENTH AVENUE CITY OF INDUSTRY, CA, 91748) dealers
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed.
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails.
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part.
11. Use of a night light may provide added safety precaution for a child using the upper bunk.
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited.
14. **STRANGULATION HAZARD** - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes.
15. Keep these instruction for future reference.
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet.
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.












ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

PARTS LIST

WF313047


1	Leg		1pc	13	Headboard frame		2pcs
2	Leg		1pc	14	Headboard panels		2pcs
3	Leg		1pc	15	Headboard panels		4pcs
4	Leg		1pc	16	Roof top support		1pc
5	Frame guard rails		1pc	17	Roof top		2pcs
6	Frame side rails		1pc	18	Roof top		1pc
7	Side rails		1pc	19	Roof top		1pc
8	Guard rails		1pc	20	Back guard rails support		2pcs
9	Guard rails		4pcs	21	Slats		14pcs
10	Door frame		1pc	22	Right stair side		1pc
11	Side door frame		1pc	23	Left stair side		1pc
12	Step stair		2pcs				

HARDWARE LIST (WF313047)

A	Ø4x30		34PCS	G	6.5x60		2PCS
B	Ø3x15		14PCS	H	4x58		1PC
C	1/4x110	 	22PCS	I	Ø10x40		42PCS
D	1/4x75	 	26PCS	J			1PC
E	1/4x65	 	4PCS	K	38x18x6		2PCS
F	1/4x30	 	11PCS		Phillip head screw Not include		

ASSEMBLY INSTRUCTIONS


Step 1



				I	Ø10x40		20PCS	
C	1/4x110			20PCS	H	4x58		1PC

ASSEMBLY INSTRUCTIONS


Step 2



I	Ø10x40		2PCS
----------	--------	---	------

C	1/4x110			2PCS	H	4x58		1PC
----------	---------	---	---	------	----------	------	---	-----

Step 3




I	Ø10x40		4PCS
----------	--------	---	------

E	1/4x65			4PCS	H	4x58		1PC
----------	--------	---	---	------	----------	------	---	-----

ASSEMBLY INSTRUCTIONS


Step 4



G	6.5x60		2PCS	I	Ø10x40		16PCS
D	1/4x75	 	26PCS	H	4x58		1PC


ASSEMBLY INSTRUCTIONS

Step 5



H	4x58		1PC	F	1/4x30			4PCS
----------	------	--	-----	----------	--------	--	--	------


Step 6



H	4x58		1PC	F	1/4x30			7PCS
----------	------	--	-----	----------	--------	--	--	------

ASSEMBLY INSTRUCTIONS

Step 7




				J		1PC
B	Ø3x15		14PCS	K		2PCS

ASSEMBLY INSTRUCTIONS

Step 8

First attach 2 pcs part 21 to the front and end of the frame, between side rails. Then attach the remaining part 21 equidistantly between side rails.



A

Ø4x30



34PCS