



Findyourniche



VERSATILE AND MODERN



ASSEMBLY INSTRUCTIONS

29" BOOKCASE PBC1629

BEFORE YOU ASSEMBLE:

- Place all parts on a clean, smooth surface to avoid scratching the parts
- Check to be sure you have all parts and hardware
- Remove all wrapping materials, including any staples & packing straps
- Keep all hardware, small parts and packaging out of reach of children

featuring



IN THE BOX:

A: Bottom



B: Side (2)



C: Kickplate



D: Shelf



G: Top



F: Back



H: Push Pin (10)



I: Shelf Pin (4)





Findyourniche



VERSATILE AND MODERN




ASSEMBLY INSTRUCTIONS

29" BOOKCASE PBC1629


STEP 1

Attach **Kickplate (C)** to **Bottom (A)** by lining up the pins with the pre-drilled slots and pressing into place. (Note: *You may need a rubber mallet as the fit can be snug.*)




STEP 2

Attach the assembled portion to the **Side (B)** by lining up the pins with the pre-drilled slots and pressing the pieces into place.




STEP 3

Attach the **Top (G)** to the assembled portion by lining up the pins with the pre-drilled slots on the **Side (B)** and pressing into place.



STEP 4

Attach the other **Side (B)** by lining up the pre-drilled holes with the pins on the **Top (G)**, **Kickplate (C)**, and **Bottom (A)** and pressing into place.





Find your
niche



VERSATILE AND MODERN



ASSEMBLY INSTRUCTIONS

29" BOOKCASE PBC1629

STEP 5

Attach **Back (F)** to the assembled bookcase by lining it up and inserting 10 **Pushpins (H)** to keep it in place. (Note: *You may need a rubber mallet as the fit can be snug.*)



STEP 6

Insert **Shelf Pins (I)** into pre-drilled holes in both **Sides (B)** where desired, and mount the **Shelves (D)**.

