

ASSEMBLY INSTRUCTION

BAR SET




WF288783, WF288784

x1



x4





NOTE:


- 1. 50% Tighten before fixing all scews, Allen wrench is recommended instead of an electric drill.
- 2. Place the item on a flat ground to adjust and make sure it remains stable.
- 3. Tighten up all screw with tools gradually.
- 4. If screw are not aligned with holes furing assembly, please loosen all the other screws to 50% and continue the assembly process.
- 5. If the item is not stable, please loosen all screws, adjust it on a flat ground and tighten up all screws again.
- 6. Note: If one or some screws are fully tighten during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

CARTON CONTENT:

WF288783









HARDWARE

WF288784










A X2
















F X2




H X2





(I)X2












SUPPORT OF TABLE 2










TABLE TOP

SUPPORT OF TABLE 1













SEAT CUSHION

SCREW


Hardware


FRONT LEG







ALLEN KEY









100 % Tighten

Put the Seat Cushion (K) on to complete the Chair.

