

**TECHNICAL DATA** 

# **PLS 6R Replacement Window Glass Insert**



### **Key features**

- Broken laser level glass? No need to buy a new laser.
- Minimize job site delays by using this quick in-field windows replacement.
- Replacement glass only for the PLS 6R red combination point and cross line laser.
- Replace damaged glass on your PLS laser affixed with just five screws.
- Please ensure your laser is operating and accurate before swapping glass inserts.

### **Product overview: PLS 6R Replacement Window Glass Insert**

PLS® Laser Levels are durable professional-grade tools that are made for reliability in harsh construction environments, but even the most rugged laser level can have its glass broken when dropped from a high enough distance. To keep contractors on schedule, Pacific Laser Systems, a Fluke company, introduces PLS Laser Level Replacement Glass Inserts, new housing glass inserts that offer a quick in-field solution to broken laser level glass.

With the new PLS HGI glass inserts, contractors can replace broken glass on their PLS laser levels on-site using a Phillipshead screwdriver, eliminating the need to take the laser level in for repair.

The glass inserts are available for PLS models 3R, 3G, 5R, 5G, 6R, 6G, 180R, and 180G.



## Ordering information



#### PLS-HGI6R

PLS HOUSING GLASS INSERT FOR PLS 6R



#### Fluke Keeping your world up and running.®

Fluke Corporation PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853 In Canada (800) 36-FLUKE From other countries +1 (425) 446-5500 www.fluke.com ©2022 Fluke Corporation. Specifications subject to change without notice. 03/2022

Modification of this document is not permitted without written permission from Fluke Corporation.