

PRODUCT INSTRUCTIONS AND WARNINGS

- 1. This toy may have potential sharp edges or cracks before assembly
Sharp points or small parts, so they must be assembled by adults.
- 2. Use the car correctly under the supervision and guidance of adults,
Otherwise, you may cause yourself or a third party injury.
- 3. It is strictly prohibited to drive and play in public streets, roads, slopes, swimming pools
and other dangerous places, otherwise it may cause traffic accidents and drowning.
- 4. This toy car may have small parts falling off during use,
so it is not suitable for children aged 3 and below.
- 5. This product is only suitable for children aged 3–8 years. Please wear it
Protective equipment, such as helmet, guard sleeve, knee pad, etc.
- 6. The car shall not be overloaded. The maximum load is 25 kg.
- 7. The charger, battery, wire, plug and other parts must be regularly checked for damage.
If any damage is found, it shall be stopped from use until it is repaired.
- 8. Keep away from fire.
- 9. Normal charging is red and full charging is green.
- 10. It is forbidden to suddenly switch forward or backward gears during normal driving.

BATTERY CHARGING AND MAINTENANCE METHOD


- 1. Please fully charge before the first use.
Only the charger and battery specified by the manufacturer can be used.
- 2. 9–10 hours for each charge, and the charging time shall not exceed 15 hours.
- 3. When the speed is obviously slow during use, it shall be charged.
In order to avoid excessive discharge and affect the battery life.
- 4. The charging must be carried out by adults. When the car is not in use,
it must be fully charged first,Then charge it at least once every 1 month,
otherwise it is very easy to cause battery damage.
- 5. During charging, the charger and battery will have slight temperature,
which is a normal phenomenon.
- 6. Waste batteries must be placed in the place designated by relevant authorities.
Please do not discard, burn or Disassemble to avoid environmental pollution.

***Children’s electric vehicle
Installation instructions***

**WARNING:**
CHOKING HAZARD– Small
parts.
Not for children under
3 yrs.
Only use the battery specified by
the manufacturer
Only use the charger specified by
the manufacturer
Please read the instructions carefully before using.

Please read the instructions carefully before use

Installation diagram



Installation steps instructions

1. Install 4 wheels and wheel covers.
2. Install the steering wheel.
3. Install the front windshield.
4. Install the rearview mirror.
5. Install the seat.
6. Install the car door glass.

NORMAL OPERATION

- 1).Before first use, loose the seat screw, open the seat and connect battery red line with the red-plug(+).
- 2).You should recharge the battery for 8-10 hours after driving the car for 1-2 hours. Don't over charge more than 15 hours.
- 3).While charging, both the charge and battery will be slightly warm.
- 4).If battery or charge is damaged, please cease to use at once until it had been repaired.
- 5).Instructions are to be kept as they contain important information.
- 6).Battery and charge are not toys.
- 7).Battery and charge should be regularly examined for damage, especially to cord, plug and enclosure.

The package contains important information, please keep it.



WARNING:

CHOKING HAZARD

— Small parts.

Not for children under 3 yrs.

Maintenance

1. Parents should check whether the main parts are in good condition, battery, charger, wire, plug, jack and other parts are damaged before use. Whether the screw is loose or not, whether there is a hidden danger in the safety, should stop using when it is found to be damaged, until it is repaired in good condition.
2. Use a little bit of lubricating to lubricate the iron part of the vehicle for a period of time to prevent wear and rust.
3. Vehicles should be placed away from the fire and avoid long-term illumination. Keep them flat and up-right. Do not lean down. In wet weather, the car should be parked indoors or covered with waterproof cloth.
4. Vehicles should be far away from the warmer objects, such as stoves and heaters, plastic parts may melt, charging, away from inflammable goods, to prevent fire.
5. Please charge in time after use. Charging must be operated by adults. If it is stored or not used for a long time, it must be charged first and then every three months. To extend battery life.
6. Use dry soft cloth to wipe the vehicle, or use non-waxy furniture polishing material instead of soft cloth to wipe the plastic parts, so as to achieve the surface polishing effect, do not use chemical solvents to wipe the plastic parts of the vehicle, do not use soap and water to clean the vehicle, do not drive in rainy or snowy weather, water will damage the motor, the vehicle's circuit system and the vehicle. Battery.
7. When stopping using or placing the product, please cut off the power supply of the product and dial all switches to "stop" or "close" position.
8. Do not use fuse that is not in conformity with the crystal specification of this product.
9. Do not change the structure and circuit system of this product without authorization. The maintenance work must be professional or technical personnel. Conduct under guidance.
10. Do not use toys for other purposes.
11. Strictly prohibit battery short circuit.
12. Rechargeable batteries can only be charged under adult monitoring.
13. The battery is put in the right polarity.
14. The exhausted batteries should be removed from toys, and should be handled well to prevent children from playing.

WARNING:

RISK OF FIRE. Do not bypass. Replace only with 7A

Do not mix old and new batteries.

Do not mix alkaline, standard (carbon-zinc), or re-chargeable batteries.

Only use the battery specified by the manufacturer.

Only use the charger specified by the manufacturer.

The battery in the vehicle is not replaceable

WARNING:

To reduce the risk of injury, adult supervision is required.

Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water, always wear shoes, and never allow more than one rider.

CAUTION

The toy is to be assembled by an adult.