

7111T60BK ASSEMBLY INSTRUCTIONS

Disclaimer:

Thank you for your purchase. Please read carefully and keep these instructions, as you may need them later.

Beware of potential electrical shock! Before installing the fixture or removing any other light already present, please turn off the main power at the circuit breaker.

If your product contains glass items, please handle with care, as glass is fragile and can lead to injuries if handled incorrectly.

Please keep in mind that the warnings and instructions present in this document are not meant to cover and prevent all possibilities and situations that could lead to injury or damage. It is the responsibility of the end-user to exercise caution and common sense when handling and installing the product.

All electrical connections must be made by qualified personnel in accordance with the National Electrical Code.

Please refer to the table below for electrical connections:

For installation, please refer to the written instructions at the back .

Need to contact us?
Please send an email at:
service@aloadecor.com

Need more information?
Please visit our website:
www.aloadecor.com

COFFEE TABLE

SKU#7111T60BK

Diameter:600mm(23.6in)

Height:36mm(14.4in)

Weight:7.9kg(17.4lb)

Included components

01 – Top of Table x1

03 – Spring washer x5 (1x spare)

06 – Wrench x1

02 – Base of Table x1


04 – Flat washer x5 (1x spare)

07 – EVA Foam sheet x1

05 – Screw nut x5 (1x spare)

Setup Directions

1. Remove all packaging material from the product and be careful not to throw away accessories that may be hidden within the packaging material. To help with assembly, lay out all components on a smooth non scratch surface.
2. Insert the screws of the table top (01) into the holes of the table base (02).
3. Add a spring washer (03), flat washer (04) and then screw nut (05) onto each screw and then tighten each screw nut using the included wrench (06).
4. Attach the EVA Foam sheet (07) to the table base (02) to protect damage to the flooring the table is placed upon.



Care & Cleaning

- This product is covered by a 12-month warranty. Please retain proof of purchase for any warranty enquiries.
- Avoid placing any sharp objects on the product, as these may damage the paint finish.
- To clean, wipe with a damp clean cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the product does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.
- Ensure any load placed on the table is evenly distributed across the surface. Any unbalanced load may cause the table to topple over.