

GoFire™

**EASILY LIGHTS CHARCOAL, LUMP COAL
OR ANY WOOD FIRE**



NEW IMPROVED FORMULA

GOFIRE is a weather proof fire starter that works under the most extreme conditions. Our proprietary formula is engineered to sustain an intense flame that can reach over one foot in height, while producing a continuous burn time up to ten minutes. **GOFIRE** pouches have a shelf life of over 30 years.

DIRECTIONS



CAMPFIRE OR FIREPLACE

Place 1-2 GOFIRE pouches in or around logs and light using the corner of the pouch as a wick.



CHARCOAL WITH CHIMNEY

Place a single GOFIRE pouch under charcoal chimney and light using the corner of the pouch as a wick. Allow Charcoal to burn for 15-20 minutes before emptying chimney.



CHARCOAL WITHOUT CHIMNEY

Without Chimney arrange charcoal into teepee shape and place 2-3 GOFIRE pouches around teepee. Light pouch using corner as wick and allow charcoal to burn 20-30 minutes.



PACKABLE & TRAVEL SAFE

100% SEALED POUCHES
- LEAVE NO WASTE BEHIND AFTER USE



KEEP OUT OF THE REACH OF CHILDREN AND PETS

GOFIRE is flammable and is intended for use outdoors or in fire-free place. Use only on non flammable surfaces and in well ventilated areas. Store away from flame or direct heat source.

CALIFORNIA PROPOSITION 65 WARNING:

This product in its natural state does not contain any toxic, harmful or cancerous materials. Please note lightning fires of any kind or burning materials, including natural wood, emits carbon monoxide and other combustion by-products. Carbon monoxide is recognized by the state of California to potentially cause cancer, birth defect or reproduce harm. To reduce risk of carbon monoxide intake, always light fires in a well ventilated area.



OUTDOOR MARKETING GROUP,
LLC, 847 PLEASANT STREET
FALL RIVER, MASSACHUSETTS 02723
WWW.OUTDOORMKT.COM

Contains N-Paraffin
DS/EN 1860-3/A1:2006
Made in Europe

