



PRODUCT KNOWLEDGE SHEET

Name: Secure Surround Play Safe Play Yard

Product #: 07240

Product Use: To create a secure area either indoors or outdoors. Great for keeping children or pets contained in a safe area; and can also be used to keep valuables off limits, such as a standing house plant. Play Yard can be configured from 4-6 panels; with the additional purchase of item #07270 another 2 panels can be added for a larger area.



General Description:

The **Secure Surround Play Safe Play Yard** 6 panel gate from Summer Infant helps you create an extra-large play area for your child at home or on the go. It is light weight, conveniently portable and easy to set up and disassemble. The door panel with handle allows you to quickly and easily get to your child and the extra-tall panels provide additional security. Take the Secure Surround Play Safe Play Yard with you to the park, beach, or on vacation to provide your little ones or even your pet with a secure play area.



- Features:**
- Convenient walk through door with handle for quick access to child without stepping over the gate
 - Door panel swings both ways
 - Extra tall 30" panels; each one is 32" wide
 - Neutral colors blend with home décor
 - 6 durable plastic panels included
 - Use 4 panels for a smaller play area or to petition an item off such as a plant; or use 6 panels for a large one
 - Inside area with 6 panels is 18 ½ square feet
 - Carry handle and light weight allow for easy portability
 - JPMA certified
 - Additional 2-sided panel extension kit sold separately (#07270)



Age Grade: Birth and Up

Manufactured: In China

Installation: Consumers should plan on about a 15 minutes for the first time they set up their Play Yard to secure all panels together. Once together, it can be taken down in just a few minutes for travel purposes. Simply loosen the knobs and fold the play yard onto itself in sequence. Then wrap the travel strap provided around the panels and snap into place. Please refer to instruction booklet for details.



PRODUCT KNOWLEDGE SHEET

Page Two: Secure Surround Play Safe Play Yard

Warnings:

- TO PREVENT FALLS, NEVER USE AT THE TOP OF THE STAIRS.
- DO NOT USE IF ANY COMPONENTS ARE MISSING OR DAMAGED.
- THIS PRODUCT IS NO SUBSTITUTE FOR PROPER ADULT SUPERVISION.
- THIS PRODUCT CONTAINS SMALL PARTS. ADULT ASSEMBLY REQUIRED.
- EXERCISE CARE WHEN UNPACKING AND ASSEMBLING PRODUCT.
- ALWAYS CLOSE GATE BEHIND YOU.
- TO PREVENT SERIOUS INJURY OR DEATH, SECURELY INSTALL GATE AND USE ACCORDING TO MANUFACTURER'S INSTRUCTIONS.
- NEVER USE WITH A CHILD ABLE TO CLIMB OVER OR DISLODGE THE GATE.
- NEVER LEAVE CHILD UNATTENDED.
- USE ONLY WITH LOCK SECURELY ENGAGED.
- DO NOT USE THIS PRODUCT IF YOUR CHILD CAN LIFT OR PUSH THE ENCLOSURE TO AN UNSAFE AREA.
- DO NOT USE NEAR STOVES OR HEATERS.
- DO NOT USE ON UNEVEN SURFACES.

Maintenance:

- Regularly check the hinge knobs to make sure the gate is securely in place.
- Do not use the gate if any components are damaged or missing.
- Wipe surface with a damp cloth or sponge using mild detergent and warm water.

Returns:

All Returns are to be RTV (Return-To-Vendor)