
# **INSTRUCTION MANUAL**




### () NOTICE Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

#### **TOOLS REQUIRED**






#### **HARDWARE**








#### **PARTS**




## PRODUCT ASSEMBLY

1

Insert two part F casters into the part C base.






## PRODUCT ASSEMBLY

3

Attach the part A right panel to the base with four part 2 screws and four part 3 washers.

Place the part H ice bucket.



## PRODUCT ASSEMBLY

