






















MX280444





PARTS LIST



		 C 8PCS	 O 1PC
		 D 4PCS	 P M6*15 24PCS
		 E 4PCS	 Q 8PCS
		 F 4PCS	 G 4PCS
		 H 8PCS	 R 1PC
		 I 1PC	 J 8PCS
		 K 1PC	 S 4PCS
 L 1PC		 M6*30 M 24PCS	 M6*40 N 16PCS
A 4PCS	B 4PCS		 T 4PCS

ASSEMBLY INSTRUCTION



①




②



③







④







ASSEMBLY INSTRUCTION

5




6



ASSEMBLY INSTRUCTION

7



ASSEMBLY INSTRUCTION

8

