


ASSEMBLY INSTRUCTION

ITEM NO.N715P340063

Dining Table



ASSEMBLY INSTRUCTION

ITEM NO.N715P340063

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION

ITEM NO.N715P340063



ASSEMBLY INSTRUCTION

ITEM NO.N715P340063

Part List

(A)





TABLE TOP (1 pc)

(B)



LEG (2 pcs)

(C)



BETWEEN LEG (2pcs)

ASSEMBLY INSTRUCTION

ITEM NO.N715P340063

Hardware List


①



Ø 5/16" x 45 mm

BOLT (12 pcs)

②



Ø 5/16" x 55 mm

BOLT (4 pcs)

③



Ø5/16" x 13 mm

LOCK WASHER (16 pcs)

④



4 mm

ALLEN KEY (1 pc)

⑤




WOOD PLUG (4 pcs)

ASSEMBLY INSTRUCTION


ITEM NO.N715P340063

STEP 1:



BOLT	LOCK WASHER	ALLEN KEY
Ø 5/16" x 55 mm	Ø5/16" x 13 mm	4 mm x 75mm
		
②x 4	③x 4	④x 1

STEP 2:





BOLT	LOCK WASHER	ALLEN KEY
Ø 5/16" x 45 mm	Ø5/16" x 13 mm	4 mm x 75mm
		
①x 12	③x 12	④x 1

ASSEMBLY INSTRUCTION

ITEM NO.N715P340063

COMPLETE



X2

⑤

WOOD PLUG



⑤ x 4