

# FRASER HILL FARM®

## 58" Dancing Santa w/ Toy Sack & Faux Lantern



I saw mommy dancing with Santa Claus! Our dancing Santa from Fraser Hill Farm will have everyone dancing and spreading holiday cheer.

Standing 58 inches tall, Dancing Santa carries his toy sack and a faux lantern. When motion is detected, he will move his arms and sway his body to the song Jingle Bell Rock.

Dressed in his fancy suit, Santa's friendly face with open spectacles, round chubby cheeks, and a full beard will warm your heart. Place him in the foyer, near the fireplace, or next to the family Christmas tree, and watch as everyone starts dancing.

- Motion-activated dancing Santa with music
- Motion sensor triggered from 1.5 to 5 feet
- Music speaker and volume knob located on base
- Enjoy animation without music via switch on base
- Recommended for indoor use only
- Assembly required - Collapsible for easy storage
- 1-year warranty

Model Number	Dimensions	Description
FSC058-2RD7	15" D x 21" W x 58" H	Dancing Santa w/ Toy Sack & Faux Lantern