


# ASSEMBLY INSTRUCTIONS


## ITEM NOTE: WF302053 DINING CHAIR













If you have any questions, please feel free to contact us.  
Email: [lowes.team@qualfurn.net](mailto:lowes.team@qualfurn.net)



### **IMPORTANT NOTE :**

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED .
- 2 BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTILL THE CHAIR FULLY SET-UP




Part List For One			Hardware List For One		
No.	Hardware Description	Q'ty	No.	Hardware Description	Q'ty
A	 Backrest	1pc	1	 Bolt Ø1/4" x 75mm	4pcs
			2	 Bolt Ø1/4" x 65mm	4pcs
			3	 Bolt Ø1/4" x 40mm	2pcs
B	 Seat frame	1pc	4	 Lock washer Ø1/4" x11x1.5mm	10pcs
C	 Front leg	1pc	5	 Flat washer Ø1/4" x16 x1.5mm	10pcs
D	 Front leg	1pc	6	 Screw #4 x 35 mm	4pcs
E	 Side support	2pcs	7	 Allen key 4 x 60 mm	1pc


ASSEMBLY TOOLS REQUIRED ( NOT INCLUDED )




## Step 1



## Step 2



## Step 3



## Step 4

