


Installation Instructions:

1. Loosen clamp and remove old hose.
2. Attach new hose to discharge stub on washing machine. Hose may be cut to ensure proper fit on 1-1/8, and 1-1/4in. studs.
3. Hang hooked end of hose over laundry tub or insert it directly into wall mounted drain outlet pipe if one is available. NOTE: In both cases it is best to attach a lint trap to the hooked end of the hose to keep your drains from clogging. Look for washing machine lint traps in this department.

Instrucciones de Instalación

1. Afloje la abrazadera y retire la manguera vieja.
2. Conecte la manguera nueva a la salida de descarga de la lavadora. Se puede cortar la manguera para asegurar un ajuste adecuado en salidas de 28.6mm. (1-1/8in.), y 31.8mm. (1-1/4in.) plug. Apriete bien la abrazadera.
3. Cuelgue el extremo enganchado de la manguera sobre la tina del lavadero o insértelo directamente en la pipa montada pared del enchufe del dren si uno está disponible. Nota: de ambos casos es la mejor unir una trampa de la pelusa al extremo enganchado de la manguera para mantener su escurrir estorbando. Busque las trampas de la pelusa de la lavadora en este departamento.



⚠ WARNING! / ¡ADVERTENCIA!

To avoid danger of suffocation, keep this bag away from babies and children. Do not use in cribs, beds, carriages or playpens. This bag is not a toy. Discard bag and any other packing materials immediately after removing product. Do not re-use this bag.

Para evitar riesgo de sofocación, mantenga esta bolsa alejada de bebés y niños. No use en cunas, camas, carriolas o corralitos. Esta bolsa no es un juguete. Tire la bolsa y los otros materiales de empaque inmediatamente. No re-use ésta bolsa.

WARRANTY: Eastman warrants this product to be free from defects in material and workmanship during normal usage for a period of one year from the date of original sale. In the event of such defects within one year, Eastman will replace the product free of charge. This product is intended for single use only and not be re-installed. Eastman shall not be liable for any damage resulting from improper use or installation.

WARRANTY: Eastman garantiza que este producto está libre de defectos en material y mano de obra durante su uso normal por un periodo de un año de la fecha de la venta original. En caso de dichos defectos durante un año, Eastman reemplazará el producto libre de cargo. Este producto está previsto para uso único y no debe ser reinstalado. Eastman no será responsable por cualquier daño causado por uso o instalación inadecuada.