
CRAFTSMAN_®


1

USE PHILLIPS HEAD SCREWDRIVER TO UNSCREW KNIFE




2

REMOVE TOP HALF OF KNIFE



3

PLACE NEW BLADE INTO REMOVABLE TRAY BY SLIDING TOP OF BLADE UP AND UNDER THE METAL TABS SO BLADE LAYS FLAT



4

REPLACE TOP HALF OF KNIFE AND USE SCREWDRIVER TO SCREW KNIFE HALVES TOGETHER

