





TV Stand w/ Fireplace

Item: YS-027

Assembly Instruction


NOTE: This instruction manual contains IMPORTANT safety information. Please read carefully before assembling the product

List of Parts



Hardware

A x 70+2




Ø6 x 34mm

B x 70+2



Ø15 x 10mm

C x 28+2



Ø8*30mm

D x 8+1



Ø3*12mm


E x 4



F x 2



G x 2



Ø4*20mm

H x 4+1



Ø3*16mm

I x 2



J x 29+2



Ø3.5*12mm

K x 12




L x 60+2




Ø3.5*14mm


M x 4



N x 3




O x 4




Ø6*25mm


P x 4



Q x 4




R x 2




STEP1

A x 12




Ø6 x 34mm




STEP2

A x 24



Ø6 x 34mm




STEP3

B x 4



Ø15 x 10mm




STEP4

B x 4



Ø15 x 10mm




STEP5

B x 8



Ø15 x 10mm




STEP6



B x 12





Ø15 x 10mm



STEP7




STEP8



STEP9

A x 8





Ø6 x 34mm

L x 8



Ø3.5*14mm

M x 4




STEP10

B x 4



Ø15 x 10mm




STEP11

B x 4



Ø15 x 10mm




STEP12

B x 8




Ø15 x 10mm

C x 8




Ø8*30mm




STEP13

A x 16




Ø6 x 34mm

O x 4



Ø6*25mm




STEP14

B x 2



Ø15 x 10mm




STEP15

B x 8




Ø15 x 10mm

C x 8



Ø8*30mm





STEP16

D x 4




Ø3*12mm

E x 2



STEP17

A x 4




Ø6 x 34mm

B x 4



Ø15 x 10mm



x2


STEP18

B x 6




Ø15 x 10mm

C x 6




Ø8*30mm




STEP19

A x 6



Ø6 x 34mm




STEP20

B x 6




Ø15 x 10mm

C x 6



Ø8*30mm




STEP21

F x 2



G x 2





Ø4*20mm

D x 4



Ø3*12mm

E x 2




STEP22



L x 8



Ø3.5*14mm





STEP23



x2

STEP24




STEP25

K x 12



TV STAND ASSEMBLY




STEP26



J x 29





Ø3.5*12mm




STEP27



Wall



STEP28




STEP25

K x 8



FIREPLACE MANTEL ASSEMBLY




STEP26



J x 19





Ø3.5*12mm




STEP27





Wall



STEP28





FIREPLACE INSTALLATION

If you decide to install the fireplace into the mantel, carefully set the unit from the back of the mantel and center it in the opening.

Check the alignment and attach the unit to the mantel by inserting screws through the drilled holes on the trim to the mantel.

NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.