



Designed for Fun, Built to Last™

LOGAN 7-FT 3-IN-1 POOL TABLE WITH BENCHES ASSEMBLY INSTRUCTIONS



Please Do Not Hesitate to
Contact Our Consumer Hotline
at 800-759-0977
with Any Questions That May
Arise During Assembly or
Use of This Product!

THANK YOU!

Thank you for purchasing this product. We work around the clock and around the globe to ensure that our products maintain the highest possible quality. However, in the rare case of issues during assembly or use of this product, please contact our Consumer Hotline at **800-759-0977** for immediate assistance before contacting your retailer. Please read the warranty information at the back of these assembly instructions for further details.

ASSEMBLY TIPS

IMPORTANT! PLEASE READ THESE ASSEMBLY INSTRUCTIONS IN ENTIRETY BEFORE ASSEMBLING YOUR PRODUCT.

1. Find a clean, level surface to begin the assembly of your game table. We recommend that two adults work together to assemble this game. You may want to carefully cut or tear the four corners of the box so that the bottom of the box can be used as your work surface.
2. Remove all of the contents from box and verify that you have all of the parts shown on the Parts List before you begin assembly. **Note: Some parts may be pre-installed or pre-assembled.**
3. Some figures or drawings may not look exactly like product.
4. **When installing parts that have more than one screw or bolt, hand tighten all screws or bolts in place before final tightening with screwdriver or wrench.**
5. Electric screwdrivers may be helpful during assembly; however, please set a **low torque** and use extreme caution because screws may be stripped or overtightened, resulting in damaged parts, if the electric screwdriver's torque is set too high.




CARE AND USE










1. This product is intended for **INDOOR** use only.
2. Do **NOT** drag the table when moving it, as this will damage the legs.

LOGAN 7-FT 3-IN-1 POOL TABLE WITH BENCHES - BG50348

Parts List





PARTS

#11 NGP7520  X1 TABLE BODY	#12 NGP7521  X2 LEFT LEG	#13 NGP7522  X2 RIGHT LEG	#14 NGP5977TK  X1 TABLE TOP A	#15 NGP5978TK  X1 TABLE TOP B	#16 NGP7523  X2 LEG END SUPPORT	#17 NGP7524  X1 LEG MIDDLE PANEL
#18 NGP7525  X2 LEG MIDDLE BRACE	#19 NGP5957  X2 BENCH	#20 NGP7526  X8 BENCH LEG	#21 NGP7527  X4 BENCH END SUPPORT	#22 NGP7528  X2 BENCH CROSS BRACE	#23 NGP7529  X2 BENCH MIDDLE SUPPORT	#24 NGP5029  X2 TABLE TENNIS BALL
#25 NGP5136  X1 BILLIARD BALL SET	#26 NGP5191  X2 2-PIECE CUE STICK	#27 NGP5135  X1 TRIANGLE	#28 NGP5077  X2 CHALK	#29 NGP5073  X1 BRUSH	#30 NGP5117 Place Under Table Top  X1 EVA SUPPORT BLOCK	#31 NGP5138  X2 TABLE TENNIS RACKET
#32 NGP50785  X4 LEG LEVELER	#33 NGP7531  X4 "L" BRACKET	#35 NGP7530 NGP5951  X1 TABLE TENNIS NET & POSTS	#37 NGP7532  X4 BENCH PLATE	#38 NGP62948  X1 TABLE BODY CROSS BRACE		




HARDWARE PACK - NGP7533

#1 X16  5/16" x 1-1/2" BOLT	#2 X14  5/16" x 2" BOLT	#3 X8  5/16" x 2-3/4" BOLT	#4 X4  5/16" x 3" BOLT	#5 X8  5/16" x 3-1/2" BOLT	#6 X4  5/16" x 4" BOLT	#7 X4  5/16" x 5" BOLT
#8 X16  BARREL NUT	#9 X60  5/16" BLACK FLAT WASHER	#10 X1  HEX WRENCH	#34 X16  5/8" SCREW	#36 X2  NUT		

ASSEMBLY INSTRUCTIONS






ASSEMBLY INSTRUCTIONS





NOTE: Attach the Leg Middle Brace (#18) to the Leg Middle Panel (#17). The Leg Middle Brace (#18) has two pre-drilled holes on one side. Attach the "L" Bracket (#33) to the pre-drilled holes on the base of the Leg Middle Brace (#18). This determines the location of where the "L" bracket attaches to the Table Body (#11).


ASSEMBLY INSTRUCTIONS (Cont.)



ASSEMBLY INSTRUCTIONS (Cont.)



ASSEMBLY INSTRUCTIONS (Cont.)



WARNING: To prevent injury, exercise caution when opening and closing bench lid. Do NOT let bench lid drop shut. Do NOT let children operate bench lid. Be cautious when moving bench on floor. EVA pads will allow bench to slide on hard flooring, but may cause tipping on carpeting. Lift bench ends to move.

180-DAY LIMITED WARRANTY

This product is warranted to the original purchaser to be free from defects in material or workmanship for a period of 180 days from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident or any other event beyond the control of the manufacturer. Defects or damage resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use; the manufacturer does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Shipping charges and insurance are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the product or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

The manufacturer shall not be liable for loss of use of the product or other consequential or incidental costs, expenses or damages incurred by the consumer of any other use. The user assumes all risk of injury resulting from the use of this product.

This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to the extent permitted by Federal or state law. Neither the manufacturer nor any of its representatives assumes any other liability in connection with this product.

All warranty claims must be made through the retailer where the product was originally purchased. A purchase receipt or other proof of date of purchase will be required to process all warranty claims. The model number and part numbers found within the assembly instructions will be required when submitting any parts requests or warranty claims.

For further warranty information or inquiries, please call 800-759-0977



Designed for Fun, Built to Last™

TABLE DE BILLARD 3 EN 1 AVEC BANCS LOGAN 2,13m INSTRUCTIONS D'ASSEMBLAGE



Contactez notre
service à la clientèle au
800-759-0977
avec des questions sur le montage
ou l'utilisation de ce produit.

MERCI!

Merci d'avoir acheté notre produit. Nous travaillons 24 heures sur 24, partout dans le monde, à garantir que nos produits sont de la meilleure qualité possible. Toutefois, dans les rares cas de problèmes lors du montage ou de l'utilisation de ce produit, se il vous plaît communiquer avec notre service à la clientèle au **800-759-0977** pour une aide immédiate avant de contacter votre revendeur. Pour obtenir de plus amples renseignements, veuillez lire l'information relative à la garantie au verso de ce guide d'instructions.

INSTRUCTIONS D'ASSEMBLAGE

IMPORTANT! VEUILLEZ LIRE, EN ENTIER, TOUTES LES INSTRUCTIONS AVANT D'ASSEMBLER VOTRE PRODUIT.


1. Trouver une surface propre et plane, pour commencer le montage de votre table de jeu. La table s'assemble à l'envers pour être ensuite retournée sur ses pieds, une fois l'assemblage complété. Cette table est lourde et nécessite au moins deux adultes forts pour la soulever et la retourner.
2. Retirez le contenu de la boîte, avant de commencer l'assemblage, assurez-vous d'avoir toutes les pièces telles que listées et illustrées au tableau d'identification. **Avis : certaines pièces sont préassemblées ou préinstallées.**
3. Certaines illustrations ou dessins peuvent ne pas ressembler au produit que vous avez acheté.
4. **Quand vous fixez en place une pièce avec plus d'une vis ou écrou, veuillez, en premier, les visser à la main et terminer la fixation avec un tournevis ou une clé.**
5. Un tournevis électrique peut être utile lors de l'assemblage, mais veuillez le régler à **basse torque** et l'utiliser avec prudence; si la torque est trop élevée, la vis peut se défaire ou être trop serrée.



ENTRETIEN ET USAGE










1. Ce produit doit être utilisé **À L'INTÉRIEUR** seulement.
2. **NE JAMAIS** déplacer la table en la traînant, cela pourrait endommager les pieds.

TABLE DE BILLARD 3 EN 1 AVEC BANCS LOGAN 2,13m - BG50348 Liste des pièces



illustrations non à l'échelle



PIÈCES

#11 NGP7520  X1 STRUCTURE PRINCIPALE	#12 NGP7521  X2 JAMBE GAUCHE	#13 NGP7522  X2 JAMBE DROITE	#14 NGP5977  X1 DESSUS DE TABLE A	#15 NGP5978  X1 DESSUS DE TABLE B	#16 NGP7523  X2 SUPPORT DE JAMBE	#17 NGP7524  X1 PANNEAU CENTRAL DE LA JAMBE
#18 NGP7525  X2 MILIEU ENTRETOISE DE JAMBE	#19 NGP5957  X2 BANC	#20 NGP7526  X8 BANC DE JAMBE	#21 NGP7527  X4 SUPPORT DE FIN DE BANC	#22 NGP7528  X2 BANC CROIX ENTRETOISE	#23 NGP7529  X2 SUPPORT CENTRAL DE BANC	#24 NGP5029  X2 BALLE DE TENNIS DE TABLE
#25 NGP5136  X1 BOULES DE BILLARD	#26 NGP5191  X2 ENSEMBLE DEUX QUEUES DE BILLARD	#27 NGP5135  X1 TRIANGLE	#28 NGP5077  X2 CRAIE	#29 NGP5073  X1 BROSSE	#30 NGP5117 <i>Place Under Table Top</i>  X1 BLOC DE SUPPORT EVA	#31 NGP5138  X2 RAQUETTE DE TENNIS DE TABLE
#32 NGP50785  X4 PIED NIVELEUR	#33 NGP7531  X4 "L" SUPPORT	#35 NGP7530 NGP5951  X1 X2 FILET ET SUPPORTS DE TENNIS DE TABLE	#37 NGP7532  X4 PLAQUE DE BANC	#38 NGP62948  X1 CROISSILLON DE CORPS DE TABLE		




SAC DE QUINCAILLERIE - NGP7533

#1 X16  BOULON (0,79 cm x 38 mm)	#2 X14  BOULON (0,79 cm x 51 mm)	#3 X8  BOULON (0,79 cm x 70 mm)	#4 X4  BOULON (0,79 cm x 76 mm)	#5 X8  BOULON (0,79 cm x 89 mm)	#6 X4  BOULON (0,79 cm x 102 mm)	#7 X4  BOULON (0,79 cm x 127 mm)
#8 X16  ÉCROU DE CANON	#9 X60  RONDELLE PLATE NOIRE (0,79 cm)	#10 X1  CLÉ HEXAGONALE	#34 X16  VIS (16 mm)	#36 X2  ÉCROU		

INSTRUCTIONS D'ASSEMBLAGE






INSTRUCTIONS D'ASSEMBLAGE





REMARQUE : Fixez l'entretoise centrale de jambe (#18) au panneau central de jambe (#17). L'attelle centrale de jambe (#18) a deux trous pré-perçés d'un côté. Fixez le support en « L » (#33) aux trous pré-perçés à la base de l'entretoise centrale de jambe (#18). Cela détermine l'emplacement de l'endroit où le support « L » se fixe au corps de la table (#11).


INSTRUCTIONS D'ASSEMBLAGE (suite)



INSTRUCTIONS D'ASSEMBLAGE (suite)



INSTRUCTIONS D'ASSEMBLAGE (suite)



AVERTISSEMENT: Pour éviter les blessures, faire preuve de prudence lors de l'ouverture et de fermer le couvercle de banc. NE LA pas le couvercle du banc arrêt de chute. NE LAISSEZ pas enfants fonctionnent couvercle du banc. Soyez prudents en se déplaçant sur le sol banc. Pavé EVA permettra banc pour glisser sur un sol dur, mais peuvent entraîner basculement sur un tapis. Ascenseur banc termine à déplacer.

GARANTIE LIMITÉE DE 180 JOURS

La garantie du produit est valide pour l'acheteur original en ce qui a trait aux pièces défectueuses ou à la main-d'œuvre pour une période de 180 jours de la date d'achat.

Cette garantie n'est couverte pas les dommages causés par accident, par modification, par une installation défectueuse ou tout autre événement hors du contrôle du fabricant. Tout défaut ou dommage résultant de la négligence ou d'une mauvaise utilisation annule cette garantie. La présente garantie ne couvre pas les égratignures ou les dommages attribuables à un usage normal.

Ce produit n'est pas destiné à un usage institutionnel ou commercial; le fabricant décline toute responsabilité pour une telle utilisation. Un usage institutionnel ou commercial annule cette garantie.

Cette garantie est non transférable et est expressément limitée à la réparation ou au remplacement du produit défectueux. Au cours de la période de garantie, le fabricant s'engage à remplacer et à réparer les pièces défectueuses sans frais pour l'acheteur. Les frais d'assurance et d'expédition ne sont pas couverts et sont à la charge de l'acheteur. Les frais de main-d'œuvre et les dépenses liées au déplacement, à l'installation ou au remplacement du produit ou de ses composantes ne sont pas couverts par cette garantie.

Le fabricant se réserve le droit de faire des substitutions de recours en garantie si la pièce n'est pas disponible ou obsolète.

Le fabricant décline toute responsabilité liée à la perte d'utilisation ainsi que tous les autres coûts directs ou indirects, frais ou dommages encourus par le consommateur qui aurait été causés par une autre utilisation. L'utilisateur assume tous les risques de dommage résultant de l'utilisation de ce produit.

Cette garantie tient lieu expressément de toute autre garantie, exprimée ou implicite, y compris les garanties de qualité marchande ou d'adaptation à un emploi particulier dans la mesure permise par les lois fédérales ou provinciales. Ni le fabricant, ni aucun de ses représentants n'assument aucune autre responsabilité en rapport avec ce produit.

Toute réclamation doit être faite par le détaillant où le produit a été acheté. Une facture ou autre preuve d'achat est nécessaire pour traiter toutes les réclamations de garantie. Le numéro de modèle et les numéros de référence figurant dans les instructions d'assemblage seront exigés lors de la soumission de demande de pièces ou de recours en garantie.

Pour plus d'information ou pour toute question, veuillez téléphoner au 1 800 759-0977.