
KOBALT



MODEL #54012 Español p. xx

KOBALT and logo design are trademarks or registered trademarks of LF, LLC. All rights reserved.

ATTACH YOUR RECEIPT HERE


Serial Number	Purchase Date




Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 888-3KOBALT (888-356-2258), 8 a.m - 8 p.m., EST, Monday - Sunday. You could also contact us at partsplus@lowes.com.

TABLE OF CONTENTS

Package Contents	3
Hardware Contents	4
Preparation	4
Safety Information	5
Assembly Instructions	6
Operating Instructions	9
Care and Maintenance	9
Troubleshooting	9
Warranty	10
Replacement Parts List	10



PART	DESCRIPTION	QUANTITY
Α	Post	2
В	Shelf	3
С	Left Bracket	3
D	Right Bracket	3



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time:15 Minutes

Tools Required for Assembly (not included): Ladder, Hammer, Tape measure, Stud finder, pencil, power drill and 1/8 in.drill bit, Phillips Screwdriver and framing square.



Please read and understand this entire manual before attempting to assemble, operate or install the product. If you have any questions regarding the product, please call customer service at 888-3KOBALT (888-356-2258), 8 a.m - 8 p.m., EST, Monday - Sunday. You could also contact us at partsplus@lowes.com.

A WARNING



PERSONAL INJURY HAZARD

Failure to properly install according to the manufacturer's guidelines could result in serious injury or death.

A WARNING



ELECTRICAL, PLUMBING OR GAS LINES MAY BE IN WALL.

Before cutting, drilling or hammering verify their location. If needed, contact your electrician, plumber, or service person.

AWARNING



POTENTIAL FALL HAZARD

During installation of this item, avoid overreaching and overextending while on a ladder.

CAUTION

POTENTIAL EYE HAZARD

Wear protective eyewear during installation.

ASSEMBLY INSTRUCTIONS

 Locate the desired position for the first vertical Post (A) on the exposed wall joist. Mark the location and drill a small pilot hole (1/8 in). Using the top-hole position of the Post (A), use screw (AA) and screw it in place to the wall joist.


NOTE: Make sure it is NOT fully tightened in place and allows for swinging side to side.

Hardware Used




ST5 x 40 mm





2. With only the top-screw in place, rotate the Post (A) 90-degree in the desired direction. Place a level on the top of the Post (A), that has been rotated 90-degree. Note: Make sure it is level and that the bottom hole of the Post (A) is on-center with the new joist. Mark the spot on the new joist using the bottom hole of the Post (A). Drill a small pilot hole (1/8 in) in this location.



3. Tighten the screws (AA) for each hole on both Posts (A).


Hardware Used



ST5 x 40 mm








ASSEMBLY INSTRUCTIONS

4. Place 3 Left Brackets (C) onto the Post(A) from the bottom up to the top as the installation procedure by upper picture showing. Using the Hammer hit the Brackets(C) down, ensure the hook touching tighten to the Post(A) as shown.Same to the Right Brackets(D).

NOTE: You can adjust the Brachet distance as needed.



5. Place Shelf (B) onto the Brackets (C & D) from the bottom up to the top ,as the installation procedure by upper picture showing. Secure the Shelf (B) to the Brackets (C & D) using Bolt(BB) and Washer (CC) tighten by a Phillips Screwdriver

Hardware Used



BB M6 x 10 mm




x 4



Ф14x1.0mm



x 4



6. Same to the other shelves as above process.

NOTE: Before installation, lay tools and components on a table or flat surface.

Hardware Used



M6 x 10 mm




x 4



Ф14x1.0mm



x 4



IMPORTANT: Using extreme caution, test the unit immediately after proper installation with a light load to double check unit is secured to the wall joint.

OPERATING INSTRUCTIONS

The Shelves are hardly to be placed onto the Brackets.

Mounting Post distance is more than 32-in.

Re-locate post distance mounting post distance to be 32-in as required.

Follow extreme caution when loading and unloading items from the 3-PC Shelf Kit. Weight load capacity is up to 150-lb per per shelf evenly distributed.

CARE AND MAINTENANCE

On an annual basis, it is recommended to double check all connections and re-tighten all nuts and bolts. Clean with water and a paper or cloth towel as needed.

TROUBLESHOOTING

If you have any questions regarding the product, please call customer service at 888-3KOBALT (888-356-2258), 8 a.m. - 8 p.m., EST, Monday - Sunday. You could also contact us at partsplus@lowes.com.

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The Shelf are hardly to be placed onto the Brackets.	Mounting Post distance is more than 32-in.	Re-locate post distance mounting post distance to be 32-in as required.

WARRANTY

You should never have a problem with your Kobalt Tools. However, if you do, return the item to the place of purchase for a free replacement. No questions asked. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state. The warranty excludes the screws.

REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 888-3KOBALT (888-356-2258), 8 a.m. - 8 p.m., EST, Monday - Sunday. You could also contact us at partsplus@lowes.com.

PART	DESCRIPTION	PART#	PIC
А	Post	5105930-A	<u>[565555655565556</u>]
В	Shelf	5105930-B	
С	Left Bracket	5105930-C	
D	Right Bracket	5105930-D	The Control of the Co
AA	Screw ST5x40mm	5105930- HAWR	
BB	Bolt M6x10mm	5105930- HAWR	
CC	Washer Φ14x1.0mm	5105930- HAWR	

Printed in China