Instruction Manual

INFORMATION AND PACKAGE

| Specification | |
|---------------|--|
| Voltage | 110-120V |
| Bulb Socket | E26 |
| Wattage | Max 40W |
| Bulb Type | Incandescent, Halogen Bulb (Not Included) |
| Certification | Socket is UL Listed |

| Package List | | |
|---------------|---|--|
| Lamp Body | 1 | |
| Crystal Cover | 3 | |
| Manual | 1 | |
| Accessory Bag | 1 | |
| | | |

A LETTER TO MY PRECIOUS CUSTOMER

Dear Customer,

Thanks for choosing this light! If you have any issue when you receive it, please contact us directly through "Contact Seller". We will offer a proper solution ASAP once receive your message. Basically, we provide online customer service during PDT 6:00pm~9:00pm (EDT 9:00pm~00:00am) from Monday to Friday. So, do not hesitate to contact us during this time frame, we will reply to you in 30 mins!

- Customer Support Team

INSTALLATION STEPS

- (1) Align the round holes on the lamp holder and the chassis, and tighten it with a nut.
- (2) Fixing the bracket: Install the bracket to the connection box by tightening 2 screws (if there is no connection box, you can also drill 2 holes, and then insert the expansion screw before installing the bracket.)
- (3) Hard-Wired: by tightening the orange wire cover (connector) clockwise, connect the black (live) wire to the "L" wire, and connect the white (zero) wire to the "N" wire.
- (4) Align the two holes on the chassis with the screws on the bracket, and then tighten them with the matching nuts.
- (5) Finally, Put the crystal cover on the socket, and fix it by tightening the black plastic ring, then install the E26 bulb.

QUESTION & ANSWER

- Q: After powering on, my lamp doesn't work. What should I do?
- A: Please check whether the lamp is really powered on as well as the switch.Please ensure the light bulbs you are using are the good ones.Please check whether the copper pieces inside the bulb socket contacts well with your bulb.

None of these 3 steps worked? Just feel free to contact us for a replacement.