






Instruction Manual

1. Default code 000



Note: no matter what code it is on the lock,
the default code is 000

2. Code setting



a. Control button at B position

b. Set code

c. Control button change to A position

3. Keep record of the new code

