


ITEM NAME/NOM D'ITEM: TEDDY DINING CHAIR


ITEM #/NO. ITEM: 109325/109328

PARTS LIST/LISTE DES PIÈCES




ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Ι



II



Please use the attached adjustable footalides to level the chair on uneven surface.

For missing parts or damaged parts, please call / Pour pièce manquante ou endommagée, veuillez appeler: USA, Canada and Mexico: (866)-798-6663