


ASSEMBLY INSTRUCTIONS




ITEM NO. FB3028CST-SC-4PK









ASSEMBLY TIPS:


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

PARTS LIST


NO.	DIAGRAM	PART NAME	Q'Ty
1		Chair Back	1PC x4
2		Seat Frame With Cushion	1PC x4
3		Leg	2PCS x4

HARDWARE LIST


NO.	DIAGRAM	PART NAME	Q'Ty
A		Bolt Ø1/4" x 1-1/2"	2PCS x4
B		Bolt Ø1/4" x 2-3/8"	4PCS x4
C		Bolt Ø1/4" x 3"	4PCS x4
D		Lock Washer Ø1/4"	10PCS x4
E		Flat Washer Ø1/4" x 19mm	10PCS x4
F		Allen key 4mm	1PC x4




STEP 1



STEP 2



STEP 3



STEP 4

