


Thank you for your purchase!



ALUMINUM FRAMED TEAK ACCENT CHAIR WITH CUSHIONS

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before your begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.



Warning:

- CHOCKING HAZARD -Small Parts. Adult Assembly Required.
- DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal crushing injuries can occur from furniture tipping over. You must install the Tipping Restraint Hardware with the unit to prevent the unit from tipping and causing any accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable the unit weight and wall materials (if not included) should be purchased and installed.

Online Assembly Instructions: <http://ftp.flashfurniture.com/AssemblyInstructions/GM-201027-1S-CH-GG.pdf>

Customer Service email: CustomerExperience@belnickinc.com | Phone: 866-552-2810

Have a Question/Concern?

Quality products and first-class customer service are the cornerstone of long-lasting consumer relationships. We strive toward excellence in all we do and want you to be completely satisfied with your purchase.

Please contact our exceptional Customer Experience Agents at the email address or phone number shown below to assist you with any product questions or issues before requesting a return.

We look forward to serving you in a friendly, efficient manner to resolve any issues you may have.

Customer Service Email: CustomerExperience@belnick.com

Customer Service Phone: 866-552-2810

Our Warranty Statement















This warranty covers manufacturing defects associated with your new product. The product is warranted from the original purchase date and to the original purchaser for normal usage, according to the below-referenced specifications and limitations.

- Non-moving metal parts are warranted for 5 years.
- Component parts including pneumatic cylinder, control mechanism, base and casters are warranted for 2 years.
- All other items are warranted for 1 year.

Normal usage means use in compliance with the restrictions and weight limits specified for the product. In the absence of product-specific restrictions and weight limits, normal usage means use for no more than forty hours per week by persons weighing 250 lbs. or less. Coverage terminates if the product is sold or otherwise transferred. Repairs made by parties other than Belnick also void this warranty.











This warranty will not cover: (1) labor, freight, or damage from misuse, abuse, negligence, alteration, assembly, installation, attachments, accident, vandalism, acts of nature or any other event beyond the control of Belnick; (2) tearing, scratching, scuffing, or blemishing of leather or fabric; (3) cosmetic damage that may result from normal usage; (4) damage attributable to use by persons exceeding specified weight limits or commercial use exceeding forty hours per week; or (5) rust or other damage caused by exposure to moisture. The user assumes all risk of injury resulting from use of this product. Liability for incidental or consequential damage is excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

PARTS

Part	Drawing	Description	QTY	Part	Drawing	Description	QTY
A		Left Armrest	1x	H		M6x70 Screw	6x
B		Right Armrest	1x	I		Washer Ring	10x
C		Back	1x	J		Nut	10x
D		Seat	1x	K		Cap A	10x
E		Back Cushion	1x	L		Allen Key	1x
F		Seat Cushion	1x	M		Wrench	1x
G		M6x40 Screw	4x	N		Cap B	10x


STEPS

STEP 1 REQUIRED PARTS








Part	Drawing	Description	QTY
A		Left Armrest	1x
B		Right Armrest	1x
C		Back Part	1x
G		M6x40 Screw	4x
I		Washer Ring	4x
J		Nut	4x
K		Cap A	4x
L		Allen Key	1x
M		Wrench	1x
N		Cap B	4x

STEP 1: From the underside of the frame, attach Left Armrest (Part A) and Right Armrest (Part B) to Back (Part C) using (4) Nuts (Part J), (4) Washer Rings (Part I), (4) M6x40 Screws (Part G) and (4) Caps (Part K).


Note: Use the Wrench (Part M) to hold the nut stationary while you tighten the screw with the Allen Key. Once completely tightened, add the Caps (Part K).





STEP 2 REQUIRED PARTS

Part	Drawing	Description	QTY
D		Seat	1x
H		M6x70 Screw	6x
I		Washer Ring	6x
J		Nut	6x
K		Cap A	6x
L		Allen Key	1x
N		Cap B	6x

STEP 2: From the underside of the frame, attach the seat (Part D) using (6) Washer Rings, (6) M6x70 Screws (Part H) and (6) Caps (Part K). Tighten the screws with the Allen Key (Part L) then install Caps.



STEP 3 PARTS REQUIRED

Part	Drawing	Description	QTY
E		Back Cushion	1x
F		Seat Cushion	1x

STEP 3: Place Seat Cushion (Part F) and Back Cushion (Part E) onto chair.

