


ASSEMBLY INSTRUCCIONES

ITEM NOTE : WF309739


DINING CHAIR





If you have any questions, please feel free to contact us.
Email: lowes.team@qualfurn.net




IMPORTANT NOTE:

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP




Part List For One			Hardware List For One		
No	Parts Desc.	Q'ty	No	Hardware Desc.	Q'ty
A	BACK FRAME 	1pcs	1	Bolts 1/4"x 35mm 	2pcs
			2	Bolts 1/4"x 75mm 	4pcs
			3	Spring Washer 1/4"x 13mm x 1.5mm 	10pcs
B	SEAT FRAME 	1pcs	4	Flat Washer 1/4"x 16mm x 1.5mm 	10pcs
			5	Bolts 1/4"x 55mm 	4pcs
C	RIGHT STRETCHER 	1pcs	6	Screws 4 x 38mm 	6pcs
D	LEFT STRETCHER 	1pcs	7	Allen Key 4mm x 60mm 	1pcs
E	FRONT STRETCHER 	1pcs			
F	FRONT LEGS (LEFT) 	1pcs			
G	FRONT LEGS (RIGHT) 	1pcs			

STEP 1




Bolts 1/4"x 35mm  ① x 2	Spring Washer 1/4"x 13mm x 1.5mm  ③ x 2	Flat Washer 1/4"x 16mm x 1.5mm  ④ x 2	Allen Key 4mm x 60mm  ⑦ x 1
--	--	--	--

STEP 2




Bolts 1/4"x 75mm  ② x 4	Spring Washer 1/4"x 13mm x 1.5mm  ③ x 4	Flat Washer 1/4"x 16mm x 1.5mm  ④ x 4	Allen Key 4mm x 60mm  ⑦ x 1
--	--	--	--

STEP 3



Screws 4 x 38mm  ⑥ x 4

STEP 4



Bolts 1/4"x 55mm  ⑤ x 4	Spring Washer 1/4"x 13mm x 1.5mm  ③ x 4	Flat Washer 1/4"x 16mm x 1.5mm  ④ x 4	Allen Key 4mm x 60mm  ⑦ x 1	Screws 4 x 38mm  ⑥ x 2
--	--	--	--	---

FINISH

