







## 34" FLIP FLOP BOOKCASES FF3430 | FFC3412 | FFSQ3412

## BEFORE YOU ASSEMBLE:

- Place all parts on a clean, smooth surface to avoid scratching the parts
- Check to be sure you have all parts and hardware
- Remove all wrapping materials, including any staples & packing straps
- Keep all hardware, small parts and packaging out of reach of children.

Unfold your bookcase and flip down shelves.

STEP 1: Then, attach the top of your bookcase by lining it up with it's respective dowels and pressing into place.




## **OPTIONAL:** Wall Anchor Instructions

Organize your parts and hardware. You will need (1) person and a Phillips head screwdriver.

## Hard ware:

A: Small Screws(2) . B: Large Screw . C: 6" Strap





STEP 2a: Attach the Strap(C) to the highest cross brace that spans the back of your bookcase with 2 Small Screws (A).

STEP 2b: Attach the Strap(C) to the wall behind the bookcase by using the Large Screw(B).

Note: Depending on the construction of your wall the Large Screw(B) should be screwed into a wallstud. If there is not wall stud available then (B) should be screwed to the wall using an appropriate wall screw (not included).

