

# **ASSEMBLY INSTRUCTIONS**



WE ENCOURAGE OUR CUSTOMERS TO LEAVE REVIEWS OF OUR PRODUCTS ON THE RETAILER'S WEBSITE WHERE THE PRODUCT WAS PURCHASED.

#### **ASSEMBLY TIPS:**

- 1 Please read the instructions carefully, and follow all assembly, operation or safety instructions properly in order to avoid damage or injury.
- 2 Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.

#### **NOTICE!**

- 1 Check All Contents Are Included Before Assembly.
- 2 Always Assemble And Disassemble The Product Under Adult Supervision.
- 3 Check The Equipment Before Each Time Use It.
- 4 Any Breakage Found On The Product, Please Stop Assembling Or Disassembling It.



WARNING: Adult Assembly Required.



#### **WARNING:**

CHOKING HAZARD -- This item contains small parts. Not suitable for children under 8 years.

#### **LIMITED WARRANTY (USA)**

TRI-GREAT USA CORP. (the "TGU") warrants the product shipped is free from defective in workmanship and materials if being used under normal/proper condition.

This Limited Warranty covers all defects in materials and workmanship for 90 days from the date of purchase, but below situation is not included:

- •Damaged through improper usage, negligence, misuse, abuse, transportation, acts of nature or accident. (including failure to follow the instructions manual)
- •Used in commercial applications or rentals.
- •Modified or repaired by anyone not authorized by TGU.
- •Expendable items such as batteries, light bulbs, fuses, accessories, cosmetic parts, tools and other items that wear out for normal usage.


Once defective point is founded after purchasing from a Retail Store, please return it along with purchasing invoice to where the unit was purchased to get further assistance.

Please Keep the Instructions Manual! The Model Number is necessary required if you have any question to contact us. Please read through it very CAREFULLY to familiarize yourself with all parts and assembly steps. Kindly refer to below parts list and be sure that all parts have been included before assembling!

Although we are dedicated to giving our customers the best product, a question may arise or parts may be missing. Once defective point is founded after purchasing from a Retail Store, please return it along with purchasing invoice to where the unit was purchased to get further assistance.


Customer Service email: service@trigreatusa.com


#### **PARTS LIST**





# **ASSEMBLY INSTRUCTIONS**


#### FIG.1































# FIG.10 (3) (13)




**FIG.12** 





**Notice:** Make sure the poles are locked.
















FIG.14-2





Please rope the velcro twice around the conner of bar. Make sure the stop net is tight.



YOU ARE NOW READY TO PLAY!

### **HOW TO FOLD THE ARCADE**




FIG.2







1. Both hand to pull up the cross bar.



1. Pull up the lock device. If you find the lock device is difficult to pull up, please pull the pole toward your position gently.



2. Turn the lock device clockwise




3. make sure the lock devices stay securely in unlock position












Press the snap button on the both poles at the same time by using both hands. Once buttons are inside the poles, please push the frame downward gently.


**Notice:** if you can't push the snap buttons at the same time, please ask someone to help.





Pull up the lower frame to 90 degree.





Push the frame downward to the end.

**Notice:** During this step, if you find the telescope tubes on each side aren't closed at the same time, please stop and pull the frame upward and repeat this action again.

# **FIG.9**FIG.9-1




#### FIG.9-2







# **HOW TO SET UP THE ARCADE**



















#### FIG.8

#### FIG.8-1




Turn the lock device anticlockwise to release the lock device. You should hear 2 "click" sounds.


FIG.8-2



Make sure the lock devices stay securely in lock position

**Notice:** If the frame still can be moved all the way to the floor, it means the lock devices are not in the lock position. Please repeat the steps again.





1. Press the snap buttons



2. Move the pole upward



3. Make sure the snap buttons are locked by plastic connector.

