

12" Multi-Function Light Stakes

Dual direction light stakes designed to give your outdoor Christmas lighting a professional look



First, position the stakes on the ground, using the string of lights as a spacing guide.

Then make a starter hole with a screwdriver or similar tool.

Install the stakes by pushing the pointed ends into the starter holes.



Attach C series lights by snapping them into the clip. For a secure fit, twist one side of the clip over the other.



Attach mini lights by crossing one side of the clip over the other so the notches overlap, then insert the base of the light into this smaller opening by squeezing the sides of the clip.



Tube or rope lights can be hung on the hook.



For a 45° light position, push tab down slightly.

For horizontal light position, push tab down further.

Multi-directional light head allows you to position the light straight up, straight down, horizontally, or at a 45-degree angle

Works with all light types, including Mini, C-Style, LED, and Rope and Tube Lights

Contoured grip for easy handling and insertion

Features a level stop, so all lights are exactly the same height

