XLUXY**SPLASH**

MAINTENANCE INSTRUCTIONS

•**Regular Cleaning:** To keep your wall tiles looking their best, regularly clean them using a soft, damp cloth or sponge and a mild, non-abrasive cleaning solution.

- •Avoid Abrasive Tools: When cleaning, refrain from using abrasive scrubbing pads or brushes that may scratch or dull the tile's finish.
- •**Prevent Stains:** Quickly wipe away any spills, splatters, or stains with a gentle cleaning solution and a soft cloth to prevent staining or discoloration.
- •Inspect for Damage: Periodically inspect your tiles for any signs of damage or loose tiles. If you notice any issues, address them promptly to prevent further damage.
- •Applications: These tiles are not suitable for use inside showers or as countertop surfaces.

Range Backsplash:

- Prior to installing a range backsplash, ensure that your stove is correctly installed according to the manufacturer's specifications.
- Tiles used as a range backsplash have a maximum temperature tolerance of 190 degrees Fahrenheit and should not come into direct contact with open flames.

