




MANHATTAN
COMFORT

ASSEMBLY INSTRUCTIONS




COD: 1021700

REV. 00


IMPORTANT REMARKS




Never climb or lean on the furniture.
You may suffer serious accidents.



Use the packaging to cover the
assembly area and separate
all parts.



Identify the parts by observing the
number printed on their edges.




CARE INSTRUCTIONS



Wipe clean using a damp cloth and a mild cleaner.
Do not use abrasive and chemical products.



HANDLING




Move the piece carefully, don't drag it. Ask
for someone else's help to do so.

HARDWARE



Identify and separate the hardware used in the assembly. There's a label on each package identifying the parts and where to use them.




STICKER-10x

COD. 7531-4x

COD. 1668-36x

COD. 0342-12x

COD. 7349-4x



A

B

C

D

E


COD. 11035-4x

COD. 0357-40x

COD. 10063-10x

COD. 7519-24x

COD. 7702-8x



F

G

H


I

J

COD. 9895-10x

COD. 8056-6x


COD. 11153-6x



K


L

M




DESCRIPTION

W:71,33in H:29.29in D: 14,94in
L:1812mm A:744mm P: 379,5mm






CÓD:1021700			
PART	QUANTITY	DESCRIPTION	BOX
01	01	BASE	01
02	02	SIDE	01
03	01	DIVIDER	01
04	01	TOP BOARD	01
05	02	BACKPLATE	01
06	02	RIGHT DOOR	02
07	02	LEFT DOOR	02
08	02	LEFT SIDE	01
09	02	BACKPLATE	01
10	02	DOOR STOP	01
50	02	STEEL BASE	03




STICKER A	COD. 7531 B	COD. 1668 C	COD. 10063 H	COD. 9895 K


01




02




03





04


COD. 0342	COD. 7349	COD. 11035	COD. 0357	COD. 7519	COD. 7702	COD. 8056	COD. 11153
D	E	F	G	I	J	L	M
							



05




06




07

COD. 7349	COD. 11035	COD. 7519
E	F	I
		



08



09

