









ITEM#3454 ASSEMBLY INSTRUCTIONS





ITEM#3454 ASSEMBLY INSTRUCTIONS

Parts List


		
HAUT LEG A X 4	CENTER LEG B X 4	BAS LEG C X 4
		
BOTTOM FRAME D X 1	FIRST SHELF FRAME E X 1	SECOND SHELF FRAME F X 1
		
TOP FRAME G X 1		

Hardware List


1  1/4 "x50mm 16pcs	2  Ø7-Ø10x1mm 16pc	3  Ø6-Ø16x1mm 16pcs
4  Ø3-10mm 16pcs	5  8pcs	6  4mm 1pc

ITEM#3454 ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM#3454 ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM#3454 ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6



ITEM#3454 ASSEMBLY INSTRUCTIONS

STEP 7

