
ITEM: N715P180449

DINING CHAIR



If you have any questions, please feel free to contact us. Email: lowes.team@qualfurn.net

ITEM: N715P180449

Important Note!


Please read these instructions fully before starting assembly:

- 1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts
- 2. Kindly follow the assembly instructions step by step.
- 3. Do not tighten all screws and bolts until the table is fully assembled.
- 4. Unscrew the protective plastique supports from the metal insert of the chair legs before assembly.
- 5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


ITEM: N715P180449




ITEM: N715P180449

Part List For One	Hardware List For One
(A)	M4*32mm WOOD SCREW (4PCS)
BACK REST (1PC)	(2) (a) (b) (b) (b) (c) (c) (d) (d) (d) (d) (d) (d) (d) (d) (d) (d
B	3
SIDE PANEL (2PCS)	SPRING WASHER (8PCS) 4
C	ALLEN KEY (1PC)
FRONT LEG (1PC)	L BRACKET (2PCS)
D	M4*12mm WOOD SCREW (4PCS)
CUSHION SEAT (1PC)	

ITEM: N715P180449





ITEM: N715P180449

COMPLETE

