

DESIGNED FOR LIFE

Assembly Instructions



Office Desk

Model No. HOGA-NY271



www.tribesigns.com

Contact Us We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.

Warm Tips

- 1. Carefully read these instructions and keep them for future reference.
- 2. Check the parts list and confirm everything's there before starting assembly.
- 3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
- 4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.

How to Get the Assembly Video



Note: If you can't find the assembly video, please contact us.



We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.











Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts. Tribosigns





Hardware List



Installation of Cams and Pins

Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening to the hole of the pin it is locking. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.



Read each step carefully before starting. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.



Disconnect the rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.



Tribosíyns







A 2 pcs



Tribosíyns









×K,

A 6 pcs



















































Tribosíyns













Screw off to fix the door left and right





Screw off to fix the door front and back







Screw off to fix the door up and down



To prevent the door hinge from falling off, please install 4 screws Hinges adjustment(Please adjust the hinges when the cabinet doors are not level or couldn't be closed)



DESIGNED FOR LIFE

Thank you for your support !



