
style NO: 6026-11895 Wood Household 3-Tier Cart





Ć

D

M

STEP 1A: Side Supports

- □ Use two short screws (B) and a hex wrench (D) to connect top and bottom left supports (8 & 9).
- □ Use two short screws (B) and a hex wrench (D) to connect top and bottom right supports (6 & 7).

С

STEP 1B: Side Frames

- □ Place two dowels (C) into the smaller holes on each small horizontal support (4) and large horizontal support (5).
- □ Install the small horizontal support (4) and large horizontal support (5) onto one side support at a time using four long screws (A) and a hex wrench (D).
- □ Repeat **step 1** to assemble the second frame.


STEP 2: Top & Middle Trays


Assembling upside-down. Use 8 short screws (B) and a hex wrench (D) to install the small top tray (1) and medium middle tray (2) between the side frames. Note: make sure the larger holes on the frames should face outward.

STEP 3: Bottom Shelf and Wheels

 \bigcirc

Install the large bottom shelf (3) using 4 short screws (B).
Using an open wrench (F) install 4 wheels (E). Make sure the locking wheels are on adjacent easily accessible side.





8680 Swinnea Road • Suite 103 • Southaven, MS • 38671

NEED HELP? For help with assembly, or if you are missing a part, please call Whitmor's Consumer Care Team, 1-888-944-8667 between 8 a.m. and 4:30 p.m. (Central Standard Time) Monday through Friday. Or email: help@whitmor.com. Visit us online at www.whitmor.com

 \mathbf{C}