

FOR ALL CERAMIC SMOOTHTOP SURFACES

General Electric®, Frigidaire®, Amana®, HotPoint®, Kenmore®, KitchenAid®, Maytag® and Whirlpool®

®Brands are registered trademarks of the manufacturers.

Magic® Glass Cooktop Cleaner & Polish cream is specially formulated for effective cleaning of glass, ceramic and porcelain cooktops. Cuts through tough grease and removes burnt on deposits without scratching, leaving a streak-free shine. Regular use will help keep your cooktop easy to clean and looking like new!

***Removes Burnt-on
Food & Spills***



***Non-Scratch,
Streak-Free Shine***



Stay Clean Protective Layer

Cooktop Surface

DIRECTIONS: Use only per label directions. Pretest in an inconspicuous area. **Shake well before use.** Remove any food from area. **1.** Turn off appliance and allow it to cool. **2.** Apply to the surface and rub with damp sponge, soft cloth or paper towel. **3.** Remove excess cleaner and buff with a clean, dry cotton cloth. Repeat as needed.

CAUTION: EYE IRRITANT: Contains calcium carbonate and detergents. Avoid contact with eyes and prolonged contact with skin. Eye Contact: Remove any contact lenses and flush with large quantities of cool running water for at least 15 minutes. Call physician if irritation persists.

KEEP OUT OF THE REACH OF CHILDREN.



MAGIC® A Premier Brand of The Homax Group, Inc.
Bellingham, WA 98226 • Made in USA
800-729-9029 • www.magicamerican.com