



1. Remove the old sink strainer. Apply plumber's putty around the top of the sink drain hole. Place the strainer body in the sink opening and press down firmly to secure it into position.
2. Position the rubber washer, followed by the metal washer, over the strainer body. Thread on the retainer and tighten the screws.
3. Slide the slip nut onto the flange tailpiece. Place the poly washer on top of the tailpiece and position it under the sink strainer. Tighten the slip nut with a wrench, ensuring not to over tighten.