


Thank you for purchasing this Winsome House product. This product has been manufactured with the highest standards of safety and quality.

Product Name:	DECO THREE DRAWER CONSOLE TABLE
SKU #:	WH197

Table Assembly:

CONTENTS					
ID	DESCRIPTION	QTY	ID	DESCRIPTION	QTY
A	 TABLE TOP	1	B	 TABLE LEG	2
C	 TUBE	1	D	 NUT	7
E	 WRENCH	1			



Assemble the table legs(B) with tube(C) use the nuts(D) and wrench(E) provided- DO NOT over tighten.



Attached the table top(A) to the legs(B) and loosely fasten the nuts(D) with wrench(E) provided- DO NOT over tighten.



Make sure all nuts are tightened.

Important:

Tighten each bolt nuts firmly. DO NOT over tighten any of the bolt nuts as this may strip the screws. DO NOT sit or stand on the table as this may damage the product and cause serious bodily injury.