

# SOLIS | LITE


**Power Button**  
Botón de encendido  
Bouton d'alimentation



**USB-C**  
USB-C  
USB Type-C

**LED Bar**  
Barra LED  
Barre LED

**Connectivity Indicators**  
Indicadores de conectividad  
Indicateurs de connectivité




**Charging Cable**  
Cable de carga  
Câble de chargement



**USB-C → USB-A Adapter**  
Adaptador USB-C -> USB-A  
Adaptateur USB-C -> USB-A

# LIGHT STATUS EN




<b>Charging in/out</b>	LED bar animates in the direction of charging
<b>Booting up</b>	LED bar animates back and forth until boot up is complete
<b>Ready to use</b>	LED bar and the three indicator lights are white
<b>Daypass waiting to be activated</b>	LED bar flashes consistently until new Daypass is activated
<b>No WiFi plan</b>	LED bar is white with 1 red light at the end of the LED bar
<b>Battery level</b>	Length of LED bar represents the battery level
<b>Firmware Update</b>	The three indicator lights flash red consistently until update is completed
<b>Failed to connect to cellular tower</b>	Signal light is red solid

# START EN

## 1 Charge

Charge hotspot with the provided charging cable. Plug the USB-C end into the USB-C port and the USB-A end into a 5V/2A power adapter (power adapter not included).



## 2 Power On

Press and hold onto the power button for 3 seconds to power on the hotspot.



## 3 Sign Up

Download the Solis WiFi App on your phone and create an account.



Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S and other countries and regions. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC.



## 4 Add Hotspot

Launch Solis WiFi App and follow the setup instructions to add the hotspot onto your account.



## 5 Buy or Activate WiFi

On the Solis App, visit the 'Shop' page to select a data plan. If you have a prepaid code, you can redeem the code on the same page.



### DAYPASSES

24-hours unlimited WiFi



### GODATA

High speed data by the Gigabyte




### UNLIMITED DATA SUBSCRIPTION

30 days unlimited WiFi, throttle limits apply

## 6 Connect Other Devices

If you want to connect other devices (e.g. laptops and tablets) to Solis WiFi, go to WiFi Settings on your devices and connect using the WiFi name and password printed on the back of the hotspot.



# HOW TO USE POWER BANK EN

## Charge Devices On-The-Go

1. Insert the USB-C to USB-A adapter into the charging port.
2. Plug your device's charging cable into the USB adapter.
3. Connect your device to the cable to begin charging!

