
Extendable Aluminum Square Dinning Table ASSEMBLY MANUAL





MODEL#: LTFA6692


Missing part? Damaged? Contact us via email at service@domioutdoorliving.com

www.domioutdoorliving.com

© Copyright 2022–2024 domi LLC. I All Rights Reserved.









Step 1:

Firstly, attach the #F, #E and #D as the picture shows, then insert the #C into A, and tighten the #F by #K to fix the #C.




Step 2:

As shown on the right, cover the #C with #B, then attach #D, #E and #F, and tighten #F with #K to completely fix the legs.




Step 3:
Hammer #G into #B to complete the leg assembly.
(Hammer is not included)


NOTE: #H is used to increase the stability when the table is fully extended, you could decide whether assemble it or not according to your needs.



Step 4: Fixing the #H onto #B with the screws (#I) included.




How to use the Extendable Table?



Step 1:

#L is used to prevent table from waggling and being damaged during transit, please DO remove it when open the table.




Step 2:

Pull out the upper table to the right side.




Step 3:

Pull out the lower table to the upper left side.




Make the lower table to the same height as the upper one, and then secure the two tables with the latch under the tabletop.

How to retract the Extendable Table?




Step 1:

Unlock the latch under the tabletop, then pull out the lower tabletop.



Step 2:

As shown in the picture, make the lower table back to its original position.



Step 3:

Push the upper tabletop back to the center of the table.

