


KOBALT®



ITEM # 2954924

Kobalt LED Neck Light

MODEL # KBLT10

KOBALT and logo design are trademarks or registered trademarks of LF, LLC. All Rights Reserved.

ATTACH YOUR RECEIPT HERE

Serial Number _____ Purchase Date _____



Questions, problems, missing parts? Before returning to your retailer, call our customer service department at **888-3KOBALT (888-356-2258)**, 8 a.m. - 8 p.m., EST, Monday - Sunday. You could also contact us at **ascs@lowes.com**.

SG24248

Prop 65 Compliant



! SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

! WARNING


- This light is water resistant, not waterproof. Do not use in wet conditions.
- Do not look at light or shine light into eyes.
- This product is not a toy. Do not leave children unsupervised with this product.
- Failure to insert batteries in the correct polarity may shorten the life batteries or cause batteries to leak.

CAUTION

- Do not dispose of in fire. This product should always be recycled or disposed of as per state and local guidelines.
- Keep this light away from flammable vapors/ liquids.

BATTERY REPLACEMENT INSTRUCTIONS

- Twist the body of the light counterclockwise so the arrows are no longer aligned.
- Remove the old batteries and insert batteries in correct polarity direction in the diagram.
- Always replace with new AA batteries. Never mix old and new batteries.
- Re-assemble and lock by twisting the body clockwise and aligning the arrows.



OPERATING INSTRUCTIONS

- There are two power switches. Each switch operates each light head separately.
- First Click - ON | HIGH
- Second Click - ON | LOW
- Third Click - OFF


WARRANTY

- 3-Year Limited Warranty

CARE AND MAINTENANCE

- Always store in a safe dry location.
- Clean the cooled lens with household window cleaner; then wipe with a soft, clean, dry cloth. Clean ABS housing with a clean, dry cloth.

KOBALT®



ARTÍCULO #2954924

Luz LED Para Cuello Kobalt

MODELO# KBLT10

KOBALT y el diseño del logotipo son marcas comerciales
o marcas registradas de LF, LLC. Todos los derechos reservados.

ADJUNTE SU RECIBO AQUÍ

Número de serie _____ Fecha de compra _____



¿Preguntas, problemas, piezas faltantes? Antes de volver a la tienda, llame a nuestro Departamento de Servicio al Cliente al **888-3KOBALT (888-356-2258)**, de lunes a domingo de 8 a.m. a 8 p.m., hora estándar del Este. También puede ponerse en contacto con nosotros a través de ascs@lowes.com.

SG24248

Cumple con la propuesta 65

! INFORMACIÓN DE SEGURIDAD

Lea y comprenda completamente este manual antes de intentar ensamblar, usar o instalar el producto.

! ADVERTENCIA


- Esta luz es resistente al agua, no impermeable. No la utilice en condiciones de humedad.
- No mire a la luz ni dirija la luz a los ojos.
- Este producto no es un juguete. No deje a los niños sin supervisión con este producto.
- Si no coloca las baterías en la polaridad adecuada, puede reducir la vida útil de las baterías o causar que estas se filtren.

PRECAUCIÓN

- No incinere las baterías. Este producto siempre se debe reciclar o desechar de acuerdo con las pautas estatales y locales.
- Mantenga esta luz alejada de vapores/líquidos inflamables.

INSTRUCCIONES PARA EL REEMPLAZO DE LAS BATERÍAS

- Gire el cuerpo de la luz en dirección contraria a las manecillas del reloj para que las flechas ya no estén alineadas.
- Retire las baterías antiguas e inserte las baterías en la dirección de polaridad correcta en el diagrama.
- Reemplácelas siempre con baterías AA nuevas. Nunca mezcle baterías nuevas y antiguas.
- Vuelva a ensamblar y bloquee girando el cuerpo en dirección de las manecillas del reloj y alineando las flechas.



INSTRUCCIONES DE FUNCIONAMIENTO

- Hay dos interruptores de encendido. Cada interruptor opera cada cabezal de luz por separado.
- Primer clic: ENCENDIDO | ALTO
- Segundo clic: ENCENDIDO | BAJO
- Tercer clic: APAGADO

GARANTÍA

- 3 año de garantía limitada

CUIDADO Y MANTENIMIENTO

- Almacene siempre en un lugar seco y seguro.
- Limpie la lente enfriada con un limpiador de ventanas doméstico; luego limpie con un paño suave, limpio y seco. Limpie la carcasa de ABS con un paño limpio y seco.

