


ASSEMBLY INSTRUCTION


DINING CHAIR



N715P272678


IMPORTANT NOTE :

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP




Part List For One Chair

9




BACKREST FRAME (1pc)

10



SEAT FRAME (1pc)


11




FRONT LEG (2pcs)

Hardware List For One Chair

G  Ø10 x 30mm	K  Ø1/4" x 13mm
WOODEN PEGS (1pc)	SPRING WASHER (10pcs)
B  Ø1/4" x 75mm	L  Ø1/4" x 19mm
BOLT (4pcs)	FLAT WASHER (10pcs)
I  Ø1/4" x 55mm	F  4 x58mm
BOLT (4pcs)	
J  Ø1/4" x 35mm	
BOLT (2pcs)	ALLENKEY (1pc)



G	Ø10x30		1PC	K	Ø1/4"x13		6PCS
B	1/4x75		4PCS	L	Ø1/4"x19		6PCS
J	1/4x35		2PCS	F	4x58		1PC



I	1/4x55		4PCS	L	Ø1/4"x19		4PCS
K	Ø1/4"x13		4PCS	F	4x58		1PC