CAROLINA CHAIR & TABLE COMPANY

Assembly Instructions Item # 42 WINDSOR ARM BENCH



1	1	-			ľ
J.		c			
			A	N	
1			5	I.	
			а.		

Thank you for purchasing a Carolina & Table Company product. This product has been designed for easy assembly and is constructed for durability. please take the time to read and follow the assembly instructions carefully. if a part or hardware is missing or you have any difficulties in assembling this product, pleasa contact us toll free at 1-800-228-3876

NO	PART LIST	QTY
1	Leg Frame - Left	1 PC
	- Right (F/R)	1 PC
2	Stretcher	2 PCS
3	Wooden Seat	1 PC
4	Chair Back Frame	1 PC
5	Assembly Arm Rest - Left	1 PC
	- Right	1 PC

NO		HARDWARE LIST	QTY
Α	\odot	Flat Washer - Dia 12mm	18 PCS
В	0	Spring Washer - Dia 12mm 🖕	18 PCS
С	0	Short JCBC Bolt M6 x 35mm	10 PCS
D	O PARTIES	Long JCBC Bolt M6 x 60mm	4 PCS
E		Long JCBC Bolt M6 x 60mm	4 PCS
F		Barrel Nut	8 PCS
G	\bigcirc	Big Wood Bottom - Dia 14.5mm	6 PCS
Н		Allen Key M4	1 PCS
Ι	0	Small Wood Bottom - Dia 11.5mm	2 PCS





IMPORTANT NOTE:

- Place all wooden part on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. • Check to be sure that you have all part and hardware. Remove all wrapping materials, inculding staples & packing straps
- before you start to assemble. Do not tighten all screws/ balts until all completely assembled
- · Keep all hardware part out of reach of children.
- DO NOT TIGHTEN BOLTS/SCREWS UNTIL ALL COMPLETELY ASSEMBLED.





j.



CARE INSTRUCTIONS

Thank you for your purchase. Our items are intended for residential use only.

To clean and maintain your furniture we recommend dry dust with a soft clean cloth.

Do not use harsh chemicals to clean your furniture as this could damage the protective top coat and/or finish.