



Fence String Light Poles

EGP-LP-0541-4 (4 Pack, Fence)



EGP-LP-0541-6 (6 Pack, Fence)





Questions? Call 1-877-969-2710 or email orders@excelloglobal.com

THANK YOU FOR PURCHASING FROM EXCELLO GLOBAL PRODUCTS!

INCLUDED PARTS

EGP-LP-0541-4 – Fence Light Pole 4 Pack	
Fence Light Pole	Installation Screw
	
x 4	x 16

EGP-LP-0541-6 – Fence Light Pole 6 Pack	
Fence Light Pole	Installation Screw
	
x 6	x 24

Missing Parts? Please Call 1-877-969-2710

Before you throw away the box, please check that you have all the parts listed below. If any are missing, please contact our customer service at the number above and we will gladly ship your replacement parts free of charge.

INSTALLATION INSTRUCTIONS


Installing the Fence Light Poles

Tools Needed:

- Impact/Drill
- Screwdriver
- Level

1. Line your pole up where you want to install it (use a level if needed), and screw into the fence/post in all four pre-drilled holes.
2. To string the lights through the pole unscrew the topper piece and thread the lighting cable through.
3. After the cable is secured, screw the topper closed to keep the string lights secured.

Note: The wire may be wrapped around the carabiner once (prior to closing the loop to further secure the string lights in place.



Fence String Light Poles

EGP-LP-0541-4 (4 Pack, Fence)

EGP-LP-0541-6 (6 Pack, Fence)



Questions? Call 1-877-969-2710 or email orders@excelloglobal.com