


Combination Lock Case

- ***When you first receive your safe your factory preset code is 0-0-0.***
- ***For security you must change the preset code after opening the safe.***

Setting Your Own Combination:

1. Set the combination (using the factory code 0-0-0 for the first time) and turn the knob clockwise to open.
2. Leave the knob turned in the open (clockwise) direction.
3. On the inside lock face, move the lever from the "A" to the "B" position.
4. Set the 3 wheel combination numbers to your own combination.
5. With the cover open, turn the knob to the locked (counterclockwise) position.
6. Return the lever on the inside lock face from "B" to "A".

Your new combination is now set.



Securing the case with the cable

To secure the case to a fixed object, loop the cable around the object and place the cable's small end into the notch on the side of the case. Locking the case will secure the cable end in the case.

You can also secure the case to a solid surface with fasteners using the mounting holes in the bottom of the case. **NOTE:** Fasteners are not included.