



Attention please :





**Improper use of screws may cause the product surface damage!
Please be careful when installing.**

**To prevent you from confusing the accessories and boards, Please
do not mix the parts of different units when you buy two or more
products at the same time.**

READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE


ASSEMBLY & INSTRUCTION MANUAL




A x22	B x22	C x26	D x 9	E x 5	F x 2	G x 1
						
			3x12mm	4x35mm	2.5x14mm	4x12mm
H x 2	I x 8	J x 1	K x 2	L x 1	M x 1	N x 1
						
O x12	P x12	Q x 2	R x 1			
						
	3x14mm	4x18mm				

The diagram illustrates the assembly of two panels, labeled 6 and 7. Panel 6 is shown in the foreground, and panel 7 is shown behind it. Both panels have pre-drilled holes for screws (A) and hinges (D). A hinge bracket (H) is used to connect the two panels. The legend in the top right corner identifies the components: A x10 (screw), D x4 (hinge), and H x2 (hinge bracket).

4




5



6

A x 4





7


B x 2



C x 2




8




B x 2



C x 2




9



A x 4




10




C x 4




E x 4



11




12



A x 4




13





B x 4



C x 4




14



B x 4




C x 4







15




D x 4





16



17



18



19

