

# User Manual

C-1190-4P

C-1190-1P












Ergonomic Design •



# Assembly Instructions



Part		Qty.
A		1
B		1
C		1
D		1
E		4
F		1
G		5
H		4
I		5

1




Diagram showing the front leg assembly (B) and rear leg assembly (C) being attached to the seat frame.

2




Diagram showing the front leg assembly (B) and rear leg assembly (C) being attached to the seat frame using a long bolt (D), washers (I), and washers (G). A hand is shown tightening the bolt. A warning label says "DO NOT TIGHTEN THIS SCREW TOO TIGHTLY".

3




Diagram showing the front leg assembly (B) and rear leg assembly (C) being attached to the seat frame using a long bolt (E), washers (I), and washers (G). A hand is shown tightening the bolt. A warning label says "100% TIGHTEN ALL THE SCREWS".

4




Diagram showing the assembled chair.

**CAUTION:**  
Make sure all bolts and screws are fully tightened before using chair. Lubricate all moving parts and tighten all bolts/screws every 6 months or whenever needed.