

SpeedTiles - Use & Care

Be sure your stove is installed according to manufacturer's standards before installing SpeedTiles as a range backsplash.

SpeedTiles installed as a range backsplash can withstand a maximum temperature of 190 degrees Fahrenheit and can't be in direct contact with flames.

The use of SpeedTiles is not recommended inside the shower or on a countertop. PEI Raiting 0.

To Clean Speedtiles, use soapy water and a clean towel.

To maintain all glass SpeedTiles models, we recommend avoiding installation in areas where there is a risk of exposure to any liquids that could cause stain of discoloration.

